


PG-PLUS

TECHNICAL PRACTICE



2 ISDN NID

Model	List	CLEI Code
PRL-773	1B	S9MSBC0A~~

Revision History of This Practice

Revision	Release Date	Revisions Made
01	September 19, 1997	Preliminary Release
02	February 19, 1999	Correct Specification Table
03	January 29, 2002	Release to rebrand document to comply with ADC standards
04	January 6, 2003	Updated Product Support Information

©Copyright 2003 ADC DSL Systems, Inc. All Rights Reserved.

ADC is a registered trademark of ADC Telecommunications, Inc. PG-Plus is a registered trademark of ADC DSL Systems, Inc. No right, license, or interest to such trademarks is granted hereunder, and you agree that you shall assert no such right, license, or interest with respect to such trademarks. Other product names mentioned in this document are used for identification purposes only and may be trademarks or registered trademarks of their respective companies.

Information contained in this document is company private to ADC DSL Systems, Inc., and shall not be modified, used, copied, reproduced or disclosed in whole or in part without the written consent of ADC.

Contents herein are current as of the date of publication. ADC reserves the right to change specifications at any time without notice. Information furnished by ADC is believed to be accurate and reliable. In no event shall ADC be liable for any damages resulting from the loss of data, loss of use, or loss of profits and ADC further disclaims any and all liability for indirect, incidental, special, consequential or other similar damages. This disclaimer of liability applies to all products, publications and services during and after the warranty period.

USING THIS PRACTICE

Three types of messages, identified by icons, appear in the text.



Notes indicate information about special circumstances.



Cautions indicate the possibility of equipment damage or the possibility of personal injury.



Electrostatic Discharge (ESD) susceptibility symbols indicate that a device or assembly is susceptible to damage from electrostatic discharge. You must wear an antistatic wrist strap connected to the appropriate ground connection prior to performing installation procedures. You must also observe normal ESD precautions when handling electronic equipment. Do not hold electronic plugs by their edges. Do not touch components or circuitry.

INSPECTING YOUR SHIPMENT

Upon receipt of the equipment:

- Unpack each container and visually inspect the contents for signs of damage. If the equipment has been damaged in transit, immediately report the extent of damage to the transportation company and to ADC. Order replacement equipment, if necessary.
- Check the packing list to ensure complete and accurate shipment of each listed item. If the shipment is short or irregular, contact ADC as described in [“Returns” on page 14](#). If you must store the equipment for a prolonged period, store the equipment in its original container.

TABLE OF CONTENTS

Overview	1
Description and Features.....	1
Metallic Fallback.....	1
Specifications.....	2
Installation	3
Required Tools and Test Equipment.....	3
Preparing the RT for Wiring.....	4
Mounting the RT.....	4
Opening the RT Housing.....	5
Wiring the RT.....	6
Attach the Frame-Ground Wire.....	8
Attach the HDSL Tip and Ring Wires.....	9
Attach the Subscriber Drop Wires.....	10
Turn up and Testing.....	11
Close the Housing.....	12
Fault Isolation	12
RT Status Indicators.....	12
COLU Fault Indicators.....	13
Product Support	14
Technical Support.....	14
Limited Warranty.....	14
Returns.....	14
FCC Class B Compliance.....	16
Modifications.....	16
Acronyms.....	17

LIST OF FIGURES

1. Typical PG-Plus Application	1
2. Mounting the RT	4
3. Securing the Customer Access Door	5
4. Accessing a Line Module	6
5. Reference Label	7
6. Attaching the Frame-Ground Wire	8
7. Attaching the HDSL Tip and Ring Wires	9
8. Inserting the Subscriber Wires	10
9. Attaching the Subscriber Wire Pair	10
10. Unplugging the RJ-11 Jack	11
11. RT Status Window	12

OVERVIEW

This practice describes the ADC® PG-Plus® PRL-773 List 1B, a PG-Plus PRL-773 (RT) that houses one RLU and provides two ISDN interfaces between the RT and two ISDN subscribers.

DESCRIPTION AND FEATURES

The PRL-773 works in conjunction with the PLL-723 COLU to interface the ISDN subscriber to the PG-Flex COTS over a single twisted-pair of wire. A PG-Flex system (see [Figure 1](#)) provides bidirectional transport of multiple DS0s over a single, unconditioned wire pair using HDSL technology. Using existing cable, PG-Flex provides for higher bandwidth needs of residential and business customers by providing an ISDN interface on a single HDSL twisted-pair wire. A minimally configured PG-Flex system consists of one COTS, one COLU, and one RT.




Figure 1. Typical PG-Plus Application

Each COLU housed in a COTS interfaces with a corresponding RT. POTS or digital lines from a CO switching system connect to the COTS and are sent by means of the COLU and the HDSL wire pair to an RT. The COTS operates on standard -48 Vdc CO battery and supplies power to the RT, eliminating the need and expense of providing local power. A PG-Flex system with HDSL transmission and line-powered RTs result in fast, cost-effective solutions to data deployment over minimal copper facilities.

METALLIC FALLBACK

Metallic fallback provides a direct connection from the CO to one subscriber under fault conditions. Service is provided to the subscriber assigned to the ISDN line in the affected COLU. At the RT, the system exits metallic fallback and attempts to synchronize if either the subscriber or the HDSL Tip to Ring pair is shorted for at least 3 seconds, and then released for at least 3 seconds. Otherwise, the COLU checks for the presence of an RT every 5 minutes. If an RT is present, the system begins HDSL synchronization acquisition. Relays in the COLU and RT under control of the PG-Flex PAU or PMU provide a path for SDT and metallic fallback operation. These relays are used to establish a circuit during fault conditions and to provide for drop testing of the selected subscriber line from the CO location.

SPECIFICATIONS

Power Supply

Voltage Safety	A2 compliant per GR-1089-CORE
HDSL Line Input Voltage	+/-135 Vdc Tip to Ring, maximum
HDSL Line Start-up Voltage	+/- 100 Vdc Tip to Ring, minimum
RT Input Power	5.8 Watts typical, 6.28 Watts with 2 ISDN sealing current enabled

HDSL Line

Line Code	2B1Q
Line Rate	196 K symbols/sec; 392 Kb/sec
Reach	12.5 kft (3.81 km), 26 AWG; 18.0 kft (5.48 km), 24 AWG; 25.2 kft (7.68 km), 22 AWG; 37.8 kft (11.5), 19 AWG
Maximum Attenuation Rate	41.6 dB at 98 kHz

Environment

Temperature	-40°F to +149°F; -40°C to + 65°C
Humidity	5 percent to 95 percent noncondensing
Altitude	-200 ft. to 13,000 ft.; -60 m to 4,000 m
Vibration	NEBS
ESD	Per GR-1089-CORE
Power and Lightning	Per GR-1089-CORE
Human Safety	UL 1950
Emissions Radiation and Immunity	Per FCC Part 15 for Class A digital devices

ISDN Interface

Interface/Line code	U Interface/2B1Q
Analog Impedance	135 Ω
Idle State Voltage	48 V minimum
Provisional Sealing Current	9 mA minimum
Bit Error Rate for ANSI 601 Loops	$< 10^{-7}$
Performance Monitoring	Interim Path
Provisional EOC	Multipoint EOC mp-eoc; transparent
Maximum Loop Length	18 kft, conforms to ANSI T1-601 Loops

Connectors

HDSL	3-terminal station protector, 3/8-inch hex nut
ISDN	Screw Terminals on RJ-11 line interface

Dimensions

Height	10.25 in. (26.0 cm.)
Width	8.5 in. (21.6 cm.)
Depth	4.75 in. (12.1 cm.)
Weight	4.0 lb. (1.8 kg.)

INSTALLATION

To ensure the safety of personnel and equipment, observe the following safety rules:



Be careful when installing or modifying telephone lines. Dangerous voltages can be present. It is unsafe to install telephone wiring during a lightning storm. Always disconnect all telephone lines and power connections before servicing or disassembling this equipment.

All wiring external to the product should follow the local wiring codes.

Always treat the HDSL pair as if it were live with high voltage present. Use caution when installing an HDSL pair that is already connected to a COLU, because dangerous voltages are present on the HDSL pair.

The COLU, unless previously disabled by means of the Craft interface, periodically attempts to power up the RT by applying +/-130 Vdc to the HDSL pair. The COLU also initiates a start-up after a momentary short has been applied to the HDSL pair. The COLU responds with start-up voltage 3 seconds after removal of the short.

The installation of an RT involves the following procedures, which are described in the following sections:

- preparing the RT for wiring
- mounting the RT
- opening the RT housing
- wiring the RT
- turn-up and testing
- closing the housing

REQUIRED TOOLS AND TEST EQUIPMENT

- ISDN U-Interface Basic Rate test set
- 1/4-inch flat-head screwdriver
- No. 1 Phillips screwdriver
- insulated-handle 3/8-inch nut driver
- 5/32-inch hex key, drilled for tamper-proof fasteners
- insulated-handle wire stripper
- insulated-handle needlenose pliers
- insulated-handle wire cutter

PREPARING THE RT FOR WIRING

HDSL and subscriber wiring are threaded through rubber grommets at the bottom of the RT. Subscriber line connections are made through the right-hand side of the Line Modules. Use a No. 1 Phillips screwdriver to punch two small holes in the bottom of the rubber grommet on the left-hand bottom side and one small hole in the right-hand grommet of the RT.

The RT is now prepared for mounting.



Cutting the grommet with a utility knife or something similar is not recommended, because this can cause too large an opening thus allowing contaminants to enter.

MOUNTING THE RT

Use the two No. 10 x 1.5-inch wood screws and flat washers provided in the Mounting Kit to attach the RT to the side of the customer residence (see [Figure 2](#)). For mounting on stucco or other suitable surfaces, use the two No. 10 x 1-inch anchor nuts from the kit.



Mount the RT only as shown, with all access openings facing down. Otherwise, possibly damaging materials (such as fluids) can enter the RT.




Figure 2. Mounting the RT

OPENING THE RT HOUSING

To gain access to the interior of the RT and to each Line Module, use a 5/32-inch drilled hex key to loosen and then remove the Telco override screw from the Customer Access or Telco Access door.

For installations that service more than one subscriber from a single RT, plug the customer-padlock hole in the Customer Access door hasp with a 3/8-inch diameter hole plug (see [Figure 3](#)) to prevent the use of a padlock. When the RT services only one subscriber, that subscriber can place a padlock through the customer-padlock hole drilled into the Customer Access door hasp to secure the Customer Access door.




Figure 3. *Securing the Customer Access Door*

Loosen the Telco override screw from the Customer Access door, or the tamper-proof screw from the Telco Access door (see [Figure 4](#)) to gain access to a Line Module. The tamper-proof screw can be one of the following:

- No. 8 pan-head pin and socket type that requires a 5/32-inch drilled hex key. The No. 8 pan-head pin and socket type screw is preferred for improved security.
- 3/8-inch hex-head screw requires a 3/8-inch nut driver (216 tool or can wrench).




Figure 4. Accessing a Line Module


WIRING THE RT

Wiring the RT consists of three major steps:

- attaching the frame-ground wire
- attaching the HDSL Tip and Ring wires
- attaching the subscriber drop wires

A wiring harness, consisting of a cable for the subscriber pairs, a cable for the HDSL pair, and a frame ground wire, is held with a strain relief as it exits the inner metal frame. The wiring harness is factory-wired to the primary protection devices for the subscriber and HDSL pairs and to the FGND bus. An additional frame ground is attached to the inner metal frame. The Line Modules on the subscriber lines provide an RJ-11 test jack for isolating trouble to the network or subscriber. Each subscriber line is protected by an over-voltage-protected threaded binding post under the Telco cover.

During installation, refer to the RT Reference label (see [Figure 5](#)) affixed inside the Customer Access door. The middle section of the Reference label identifies the Frame Ground and HDSL Tip and Ring wires, and the wire color code for the subscriber lines.



PG-Plus

2 ISDN REMOTE TERMINAL

PRL-773 LIST

ON: POWER NORMAL/HDSL SYNC
 FLASH: POWER NORMAL/NO SYNC
 OFF: NO POWER

ON: RT FAULT
 FLASH: SUBSCRIBER DROP TEST
 OFF: NORMAL





ON: CHANNEL(S) ACTIVE
 FLASH: RINGING
 OFF: ALL CHANNELS IDLE

POWER

STATUS


ACTIVITY

CONNECTION _____ TIP / RING

	ISDN-2 (LINE 2)	WHT/ORG
	ISDN-1 (LINE 1)	WHT/BLU
	HDSL	BLK/YEL
	FGND	GREEN

INPUT: 280VDC 0.1AMP

LISTED NID 32FF



THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRE OPERATION.

CAUTION

RISK OF ELECTRICAL SHOCK. VOLTAGES UP TO 280 VDC MAY BE PRESENT ON TELECOMMUNICATIONS CIRCUITS.

WARNING

CONNECT FRAME GROUND TO EARTH GROUND. FAILURE TO DO SO MAY RESULT IN DAMAGE TO THE UNIT AND RISK OF ELECTRICAL SHOCK.




Figure 5. Reference Label

Attach the Frame-Ground Wire

- 1 Open the Telco Access door.
- 2 Insert the FGND wire through one of the holes in the left-hand rubber grommet. A 10 AWG (25.8 mm) solid copper ground wire is recommended.




Figure 6. Attaching the Frame-Ground Wire

- 3 Loosen and remove the top nut and three flat washers from the ground-binding post.
- 4 Loop the FGND wire around the ground-binding post. Then replace and tighten, in reverse order, the hardware removed earlier.

Attach the HDSL Tip and Ring Wires

HDSL and subscriber wiring are threaded through rubber grommets at the bottom of the RT. The HDSL pair from the COTS is terminated on an over-voltage-protected threaded binding post at the bottom of the enclosure and connected to the HDSL pair in the wiring harness.



Always treat the HDSL pair as if it were live with high voltage present. Review the safety precautions at the beginning of this section before proceeding.

- 1 Insert the service cable containing the HDSL Tip and Ring wires into the second hole in the bottom of the left-hand rubber grommet.




Figure 7. Attaching the HDSL Tip and Ring Wires

- 2 Loosen the top nuts on the Tip and Ring gas-tube protection binding posts (see [Figure 7](#)).
- 3 Remove the service cable outer jacket from the cable inside the RT, strip the insulation from the end of the HDSL Ring wire using an insulated-handle wire stripper, then carefully insert and loop the HDSL Ring wire in a clockwise direction between the top two washers on the HDSL Ring binding post.



To avoid electrical shock, handle the stripped HDSL wire by its insulation with insulated-handled needlenose pliers

- 4 Tighten the HDSL Ring binding post nut with an insulated-handle nut driver, then trim any excess uninsulated wire with an insulated-handle wire cutter.
- 5 Connect the Tip conductor as done with the Ring conductor.

Attach the Subscriber Drop Wires

Subscriber line connections are made through the right-hand side of the Line Modules. An RJ-11 jack allows the subscriber line to be disconnected from the network, or allows for a test set to be plugged in as an aid to diagnostic tests.

Each subscriber line is protected by an over-voltage-protected threaded binding post under the Telco cover. If this unit has been pole mounted, ADC recommends that the subscriber drop wires be connected directly to the appropriate gas-tube protection binding posts.

- 1 Thread the subscriber wire pairs through the hole made earlier in the right-hand rubber grommet (see [Figure 8](#)).
- 2 Lift the Line Module door, and insert the subscriber wire pair through the cutout on the right side of the Line Module door. The HDSL Tip and Ring wires, which you installed in the previous section, are not shown in this graphic.




Figure 8. *Inserting the Subscriber Wires*

- 3 Connect the Tip conductor to the Line Module green terminal gas-tube protection binding post, connect the Ring conductor to the red terminal gas-tube protection binding post, then close the Line Module door (see [Figure 9](#)).




Figure 9. *Attaching the Subscriber Wire Pair*

- 4 Repeat the steps for each additional subscriber line being installed.
- 5 Close the Line Module door.

TURN UP AND TESTING

- 1 Open the line module door and disconnect all the ISDN RJ-11 jacks (see Figure 10). The Activity LED is Off.




Figure 10. Unplugging the RJ-11 Jack

- 2 Configure the ISDN U-Interface Basic Rate test set appropriately.
- 3 Connect the ISDN test set to the ISDN RJ-11 jack.
- 4 The ISDN test set should acquire synchronization in approximately 30 to 60 seconds.
- 5 Verify that the Activity LED is On green. This happens only if, on the CO end, the ISDN is connected to the ISDN switch.
- 6 Perform the necessary ISDN turn-up tests through the ISDN test set.
- 7 Disconnect the ISDN test set from the ISDN RJ-11 jack.
- 8 Reconnect the ISDN RJ-11 jacks and close all the Line Module doors and the Telco Access door.

CLOSE THE HOUSING

- 1 If you have not already done so, close the Line Module door.
- 2 If you have not already done so, close the Telco Access door.
- 3 To avoid interference with the RT cover, tighten the screw on the Telco Access door until it is completely seated.
- 4 Close the RT housing cover and secure both the Telco override screw and the slotted-head Customer Access screw.

FAULT ISOLATION

The following sections detail the fault isolation procedures. For sections that indicate a condition such as “distance limitation exceeded”, refer to “[Specifications 2](#) for the correct values.

RT STATUS INDICATORS

You can view the LEDs status through the window of the RT case. These LEDs indicate system states and subscriber line activity. The top portion of the label is a guide to the meaning of the Status LEDs (see [Figure 11](#)).




Figure 11. RT Status Window

If the PWR LED is Off, perform the following operations:

- 1 Verify that the RT and its corresponding COLU are installed on the same pair.
- 2 Verify the COLU is installed and turned up, and that the HDSL Periodical Power Up option is enabled.
- 3 Verify that the signal loss on the pair is no more than 41.6 dB at 98 kHz.
- 4 Check for a short placed on the HDSL Tip and Ring conductors, and remove if necessary.
- 5 Check for HDSL cable fault, and replace if necessary.
- 6 Verify that the line length does not exceed the values supported (see “[Specifications 2](#)). The distances provide 10^{-7} BER with 6 dB of margin. The distances supported over single-gauge cable, without the use of bridge taps, for the RT are listed in the Specifications.
- 7 Replace the RT and if necessary, replace the corresponding COLU.

COLU FAULT INDICATORS

At the CO, you can use the VT-100 terminal to initiate a SDT to determine the cause of any of the following problems. The following sections provide procedures for isolating faults indicated by the COLU LEDs.

LED	Mode	Condition	Procedure
None	On	processor in the COLU stopped	1 Remove and re-insert the COLU.
			2 At the VT-100 interface, go to the COLU Main screen to view the Performance report to verify that no alarms exist. If the COLU Main screen cannot be viewed, a communication error exists, indicating a faulty COLU.
			3 If the LEDs do not illuminate, replace the COLU.
Fault	On	indicates an existing alarm condition on the COLU	1 At the VT-100 interface, go to the COLU Main screen to view the Performance report to determine the cause of the alarm. Correct the condition, if possible. If the COLU Main screen cannot be viewed, a communication error exists.
			2 Remove and re-insert the COLU.
			3 If the communication error still exists, replace the COLU.
Margi n	On	<ul style="list-style-type: none"> • distance limitation exceeded • fault in HDSL line • faulty COLU 	1 At the VT-100 interface, go to the COLU Main screen to view the Performance report to verify that no alarms exist.
			2 Initial installation, check engineering records for distance between COTS and RT.
			3 If existing installation, measure loss of HDSL line to ensure that the maximum attenuation value has not been exceeded.
			4 Replace COLU and/or the RT.
Margi n	Flashing	<ul style="list-style-type: none"> • distance limitation exceeded • fault in HDSL line • faulty RT 	1 Initial installation, check engineering records for distance between COTS and RT.
			2 If existing installation, measure loss of HDSL line to ensure that the maximum attenuation value has not been exceeded.
			3 Replace the Colu or the RT or both.
SYNC	Off	<ul style="list-style-type: none"> • HDSL line has lost synchronization • distance limitation may have been exceeded • COLU is faulty 	1 Initial installation, check engineering records for distance between COTS and RT.
			2 If existing installation, measure loss of HDSL line to ensure that the maximum attenuation value has not been exceeded.
			3 Replace the Colu or the RT or both.
PWR	Off	<ul style="list-style-type: none"> • no input power • on-board fuse is blown on COLU 	1 Ground fault condition exists.
			2 Check input power at COTS backplane with COLU removed.
			3 If power is present at COTS backplane, replace the COLU.
PWR	Flashing	<ul style="list-style-type: none"> • HDSL line open • an overload exists 	1 Check line continuity and resistance.
			2 COLU power supply or RT may be faulty.

PRODUCT SUPPORT

TECHNICAL SUPPORT

Technical Assistance is available 24 hours a day, 7 days a week by the contacting Customer Service Engineering group at:

Telephone: 800.366.3891
The 800 telephone support line is toll-free in the U.S. and Canada.

Email: wsd_support@adc.com

Knowledge Base: http://adc.com/Knowledge_Base/index.jsp

Web: www.adc.com

LIMITED WARRANTY

Product warranty is determined by your service agreement. Refer to the ADC Warranty/Software Handbook for additional information, or contact your sales representative or Customer Service for details.

RETURNS

To return equipment to ADC:

- 1 Locate the number of the purchase order under which the equipment was purchased. To obtain a return authorization number, you need to provide the original purchase order number to ADC's Return Material Authorization (RMA) Department.
- 2 Call or write ADC's RMA Department to ask for an RMA number and any additional instructions. Use the telephone number, fax number or email address listed below:
 - Telephone: 800.366.3891
 - Email Address: rma@ADC.com
- 3 Include the following information, in writing, along with the equipment you are returning:
 - Company name and address.
 - Contact name and telephone number.
 - The shipping address to which ADC should return the repaired equipment.
 - The original purchase order number.
 - A description of the equipment that includes the model and part number of each unit being returned, as well as the number of units that you are returning.
 - The reason for the return. For example:
 - The equipment needs an ECO/ECN upgrade.
 - The equipment is defective.



If the equipment is defective, please tell us what you observed just before the equipment malfunctioned. Be as detailed in your description as possible.

If there is another reason for returning the equipment, please let us know so we can determine how best to help you.

- 4 Pack the equipment in a shipping carton.
- 5 Write ADC's address and the RMA Number you received from the RMA Department clearly on the outside of the carton and return to:

ADC DSL Systems, Inc.
14352 Franklin Ave.
Tustin, CA 92780-7013

Attention: **RMA (Number)**



All shipments are to be returned prepaid. ADC will not accept any collect shipments.

FCC CLASS B COMPLIANCE

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- * Reorient or relocate the receiving antenna.
- * Increase the separation between the equipment and receiver.
- * Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- * Consult the dealer or an experienced radio/TV technician for help.

Modifications

The FCC requires the user to be notified that any changes or modifications made to this device that are not expressly approved by ADC voids the user's warranty.

All wiring external to the product(s) should follow the provisions of the current edition of the National Electrical Code.

ACRONYMS

ACO	Alarm Cut-Off. Reset and test switch for Alarm Unit of PG-Plus.
CO	Central Office
COLU	Central Office Line Unit
COTS	Central Office Terminal Shelf. PG-Plus Central Office Shelf including line units and common equipment.
DS0	Digital Signal Zero. A single 64 kbs channel of a DS1 signal.
DS1	Digital Signal One. A 1.544 Mbps digital carrier signal.
ESD	Electrostatic Discharge
HDSL	High-bit-rate Digital Subscriber Line
ISDN	Integrated Services Digital Network
LED	Light Emitting Diode
MLT	Mechanized loop Testing. Per TA297, description of subscriber loop method.
MSL	Mean Sea Level
NEBS	Network Equipment-Building System. Bellcore Generic Requirements GR-63-CORE.
PAU	PG-Plus Alarm Unit. PG-Plus Alarm and Systems Interface Unit.
PMU	PG-Plus Management Unit
PMX	PG-Plus Multiplexer Unit
POTS	Plain Old Telephone Service
REN	Ringer Equivalence. A number.
RLU	Remote Line Unit. PG-Plus HDSL Interface Unit.
RMA	Return Materials Authorization
RT	Remote Terminal (enclosure and RLU inclusive)
SDT	Subscriber Drop Test

World Headquarters:

ADC Telecommunications, Inc.
12501 Whitewater Drive
Minnetonka, Minnesota USA 55343

For Technical Assistance:

800.366.3891



1251806
