

# PAIRGAIN™ TECHNOLOGIES HiGain-2™ LINE UNIT MODEL HLU-611 Issue 1

List 1, PairGain #150-1217-01, CLEI Code: T1LIUC04AA

CONTENTS	PAGE
A. PRODUCT OVERVIEW	2
1. DESCRIPTION AND FEATURES	2
2. APPLICATIONS	2
3. SPECIFICATIONS	3
4. CERTIFICATION	3
5. WARRANTY	3
6. TECHNICAL ASSISTANCE	4
B. FUNCTIONAL DESCRIPTION	4
7. FUNCTIONAL OPERATION	4
8. OPTIONS	7
9. LOOPBACKS	9
C. INSTALLATION AND TEST	10
10. INSTALLATION	10
11. TESTING	10

**CAUTION**  
 This product incorporates static sensitive components. Proper electrostatic discharge procedures must be followed.




Figure 1. HLU-611 Front Panel. The PairGain HLU-611 is the Central Office side of a single pair repeaterless T1 transmission system.

**A. PRODUCT OVERVIEW**

**1. DESCRIPTION AND FEATURES**

**1.01** PairGain’s HiGain-2 Line Unit Model HLU-611 Issue 1, List 1 (Figure 1), is the Central Office side of a single pair repeaterless T1 transmission system. When used in conjunction with an HRU-612 HiGain-2 Remote Unit, the system provides 1.544 Mbps transmission on one unconditioned copper pair over the cable ranges shown in Table 1. The HiGain-2 system uses VHDSL (Very High-bit-rate Digital Subscriber Line) transmission technology. HiGain-2 complies with TR-TSY-000063 (Network Equipment Building System (NEBS) Generic Equipment requirements) and TR-TSY-000499 (Transport System Generic Requirements - TSGR) common requirements.

**1.02** Revision History of this practice.

**Release 02 — September 7, 1995**

a) Revised format.

**1.03** HLU-611, List 1 features:

- Selectable DSX-1 Pre-equalizer
- -170 Vdc Line Power for HRU-612
- Front Panel VHDSL S/N Margin Display
- Selectable Loopback activation codes
- RS-232 maintenance port
- Non-volatile front-panel operator setup
- Front Panel DS1 splitting and bridge access
- Lightning and power cross-protection on VHDSL interfaces
- 1.568 Mbps full-duplex 2B1Q VHDSL Transmission on a single pair
- Front panel status indicating LED

- On/Off front-panel display power cycling
- DS1 LOS detector (125 consecutive zeros)
- Margin threshold alarm
- Smart-Jack AIS option
- Easy return-to-factory-default user settings
- Circuit ID option

**2. APPLICATIONS**

**2.01** HiGain-2 provides a cost-effective, easy-to-deploy method for delivering T1 High Capacity Digital Service (HCDS) over one metallic pair. The fiber-like quality service is deployed over one unconditioned, non-loaded copper pair. Conventional in-line T1 repeaters are not required. Cable pair conditioning, pair separation and bridged tap removal are not required.

**2.02** The general guidelines on which the range deployment rules in Table 1 are based require that each HiGain-2 loop has less than 38 dB of loss at the 2B1Q line rate of 392 kHz, with 135 ohm driving and terminating impedances. Adherence to this rule will result in an operating margin of at least 6 dB. The HiGain-2 system operates with any number of other T1, POTS, Digital Data Service (DDS) or other HiGain-2 Systems sharing the same cable binder group. HiGain-2 systems can be used with customers requiring DS1 service on a temporary or permanent basis. HiGain-2 also provides a means of quickly deploying service in advance of fiber-optic transmission systems. With HiGain-2, service can be provided within hours. Fiber optic systems can be installed at a leisurely pace and cut-over from HiGain-2 when convenient to do so. The HiGain-2 system can then be easily removed and utilized elsewhere.

**TABLE 1. HIGAIN-1 VHDSL LOOP LIMITS**

Cable Gauge	Loss at 392 kHz dB/kft	Ohms per kft	Maximum Loop For 35 dB Loss	Ohms at Maximum Loop Length
26/0.4 mm	4.97	83.3	7 kft / 2.13 km	583
24/0.51 mm	3.87	51.9	9 kft / 2.74 km	467
22/0.61 mm	3.01	32.4	12 kft / 3.66 km	389
19/0.91 mm	2.17	16.1	16 kft / 4.87 km	258

### 3. SPECIFICATIONS

#### VHDSL Line Code

1.568 Mbps 2B1Q.

#### VHDSL Output

+13.5 dBm  $\pm$  0.5 dB at 135 ohms.

#### VHDSL Line Impedance

135 ohms.

#### Maximum Provisioning Loss

38 dB at 392 kHz, 135 ohms.

#### Line Clock Rate

Internal Stratum 4 clock.

#### VHDSL Startup Time

30 seconds (typical), 60 seconds (maximum)

#### One-way DS1 Delay

<220 microseconds.

#### DSX-1 Line Impedance

100 ohms.

#### DSX-1 Pulse Output

12 V pk-pk for EXTERNAL equalizer or pre-equalized for 0-655 feet of ABAM.

#### DSX-1 Input Level

+1.5 to -7.5 dB DSX.

#### DS1 Line Rate

1.544 Mbps  $\pm$ 200 bps.

#### DS1 Line Format

AMI, B8ZS or ZBTISI.

#### DS1 Frame Format

ESF, SF or unframed.

#### Power Consumption

14 Watts (typical), 18 Watts (maximum).

#### Heat Dissipation

6 Watts (typical), 8 Watts (maximum).

#### Fusing

Internal; connected to "FUSEALARM" output on pin 32.

#### Span Voltage

-170 Vdc maximum.

#### Margin Indicator

Displays span SNR margin for both spans relative to  $10^{-7}$  BER operation.

#### Electrical Protection

Secondary surge protection on DS1 and VHDSL ports. Power cross protection on VHDSL port.

#### Operating Temperature and Humidity (non-condensing)

0° to 50° Celsius, 5-95% humidity.

#### Mounting

AT&T 220 type or equivalent.

#### Dimensions

Height: 5.9 in.

Width: 1.4 in.

Depth: 10 in.

#### Weight

1.26 lbs.

### 4. CERTIFICATION

**4.01** FCC compliance: The HLU-611 has been tested and found to comply with the limits for a Class A digital devices pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

### 5. WARRANTY

**5.01** PairGain Technologies warrants this product to be free of defects and fully functional for a period of 36 months from the date of original shipment, given proper installation. PairGain will repair or replace any unit without cost during this period if the unit is defective for any reason other than abuse, improper use or incorrect installation.

**5.02** This module should not be field repaired. If it fails, replace it with another unit and return the faulty unit to PairGain for repair. Any modifications of the unit by anyone other than an authorized PairGain representative will void the warranty.

**5.03** If a unit needs repair, call PairGain for a Return Material Authorization (RMA) number and return the defective unit, freight prepaid, along with a brief description of the problem, to:

**PairGain Technologies, Inc.**  
**14402 Franklin Avenue**  
**Tustin, CA 92680**  
**ATTN: Repair and Return Dept.**  
**(714) 832-9922**  
**(800) 638-0031**

## 6. TECHNICAL ASSISTANCE

**6.01** PairGain Technical Assistance is available 24-hours-a-day, 7-days-a-week by contacting PairGain's Customer Service Engineering group at one of the following numbers:

**Telephone: (800) 638-0031  
(714) 832-9922**

**Fax: (714) 832-9924**

During normal business hours (8:00 AM to 5:00 PM, Pacific Time, Monday - Friday, excluding holidays), technical assistance calls are answered directly by a Customer Service Engineer. At other times, a request for technical assistance is handled by an on-duty Customer Service Engineer through a callback process. This process results in a callback within 30 minutes of initiating the request.

In addition, PairGain maintains a computer bulletin board system for obtaining current information on PairGain products, product troubleshooting tips and aids, accessing helpful utilities, and for posting requests or questions. This system is available 24-

hours-a-day by calling (714) 730-3299.

Transmission speeds up to 28.8 kbps are supported with a character format of 8-N-1.

## B. FUNCTIONAL DESCRIPTION

### 7. FUNCTIONAL OPERATION

**7.01** HiGain-2 utilizes PairGain's 2B1Q VHDSL transceiver systems to establish one full-duplex 1.568 kbps data channels between the HLU-611 and a remotely mounted HRU-612 HiGain-2 Remote Unit.

**7.02** A block diagram of the HLU-611 is shown in Figure 2. The HiGain-2 HLU-611 receives a 1.544 Mbps DS1 data stream from the DSX-1 digital cross connect interface. The HLU contains a DS1 frame synchronizer controlled by an 8 bit micro controller that determines the type of framing on the DS1 stream and synchronizes to it. The HLU-611 recognizes SF (including D4) or ESF framing. When the data is unframed, the HLU-611 arbitrarily defines a frame bit.




Figure 2. HLU-611 Block Diagram.

- 7.03** The HLU-611 contains a demultiplexer that generates a 1.568 kbps data stream. The data stream contains VHDSL frames that are nominally 9,408 bits (6 milliseconds) in length. The VHDSL frames contains a 14 bit Frame Sync Word (FSW), 6 bit Cyclic Redundancy Check (CRC), 21 bit operations channel and DS1 payload.
- 7.04** The formatted VHDSL channel is passed to the VHDSL transceiver which converts it to a 2B1Q format on the VHDSL line. The 2B1Q line code is designed to operate in a full-duplex mode on one unconditioned pair. The transceiver's echo canceler and adaptive equalizer receive the signal from the remote end in the presence of impairments and noise on the copper pair.
- 7.05** The received VHDSL channel is processed by the transceiver and then passed on to the HLU-611 multiplexer module. The multiplexer provides frame synchronization for the VHDSL channel. The multiplexer and VHDSL transceiver work under control of the HLU-611 micro controller and compensate for data inversions caused by tip-ringing reversals. By synchronizing to the FSW of the VHDSL channel, the multiplexer can reconstruct the original 1.544 Mbps DS1 stream from the VHDSL channel. The CRC fields on the VHDSL streams allow the HLU-611 to determine if errors are present on the channel due to excessive impairments on the VHDSL pairs or due to excessive impulse or crosstalk noise.
- 7.06** The multiplexer removes data link messages from the VHDSL channel and passes them to the micro controller. This mechanism allows operations messages and status to be exchanged between the HLU-611 and the HRU-612 remote unit.
- 7.07** The reconstructed VHDSL data channel is buffered in a first-in-first-out buffer (FIFO) within the multiplexer. A frequency synthesizer in conjunction with the FIFO regulates the output bit rate and reconstructs the DS1 clock at the exact rate received from the remote end. The HiGain-2 system operates at DS1 rates of 1.544 Mbps with up to  $\pm 200$  bps of offset.
- 7.08** A DSX-1 interface driver converts the DS1 channel to an AMI or B8ZS format. The DSX-1 equalizer is programmable to 5 different lengths as determined by the distance between the HLU and the DSX-1 interface. This provides CB-119 compliant pulses at the DSX-1 interface over a range of 0-655 feet of ABAM cable.

**7.09** The HLU-611 contains two separate power converters. The main power supply converts -48 V local battery to logic power for the HLU-611 circuits. The line power supply converts the -48 V battery to a -170 Vdc feed that provides loop power feed on the cable pair to the HRU Unit. The line power supply can be turned on or off by the micro controller and is automatically shut down in the presence of line short circuits or micro controller failure.

**7.10** The three most important power demands of an HLU-611 on the shelf power supply are its maximum power consumption, its maximum power dissipation and its maximum current drain. These three parameters for the HLU-611, on a per slot and per shelf basis, are as follows:

**Maximum Power Dissipation:**

- Per Slot = 8.0 Watts
- Per Shelf = 104 Watts

**Maximum Power consumption:**

- Per Slot = 18 Watts
- Per Shelf = 234 Watts

**Maximum Current Drain:**

- Per Slot = 0.423 A
- Per Shelf = 5.5 A

Note that the worse case conditions under which these parameters were measured include a 7,500 ft. # 26 AWG loop, 60 mA of CPE current, a fully loaded 13 slot shelf, and a 42.5 V shelf battery voltage.

**7.11** The Maximum Power Dissipation measures the power that is converted into heat build up within the unit. It contributes to the total heat generated in the space around the unit. It is used to determine the maximum number of fully loaded shelves per bay that does not exceed the maximum allowable power dissipation density in Watts/sq. ft.

**7.12** In Central Office locations, the maximum power dissipation for open faced, natural convection cooled mountings is limited to 120 W / sq. ft. per Section 4.2.3 of the NEBS standard TR-NWT-000063. The footprint of a 13 slot 23" HLU-611 shelf is 7.024 sq. ft. Thus the maximum bay dissipation is limited to 840 Watts. At 104 Watts per shelf, this limits the number of fully loaded HLU-611 shelves to 8 per bay. Note that this is a worse case situation in that it assumes the entire Central Office is subjected to the maximum power density. Conditions other than these worse case ones would permit increasing the number of shelves per bay without jeopardizing the C.O.'s thermal integrity.

**7.13** The thermal loading limitations imposed when using the HLU-611 in CEVs or other enclosures are determined by applying the HLU-611's power parameters to the manufacturer's requirements for each specific housing.

**7.14** The Maximum Power Consumption is the total power that the HLU-611 consumes or draws from its -48 V shelf power source. This parameter is needed when the 611 is located remote to its serving C.O. It determines the battery capacity required to maintain an 8 hour stand-by battery reserve for emergency situations. It thus limits the maximum number of plugs per remote enclosure. Use the above data to perform this analysis on a case by case basis.

**7.15** The Maximum Current Drain is the maximum current drawn from the shelf power supply when it is at its minimum voltage (42.5 V). This determines the shelf fusing requirements. HLU-611 shelves are fused at 10 A. A fully loaded shelf of 13 HLU-611s draws 5.5 A in the worst case. This is well within the 10 A fuse limit.

**7.16** A 9-pin (RS-232) DB-9 connector (see Figure 3), is provided on the front panel. This connector provides access to HiGain-2's maintenance, provisioning and performance monitoring interface. A very basic interface is available via a 'dumb terminal'. Figures 7 through 13 show the menu selections that are available from the terminal. The port is configured as DCE with 8 data bits, one stop bit and no parity. Striking the SPACE bar several times invokes autobaud from 1200 to 9600 bps.

**7.17** The normally open alarm contacts available across pins 20 and 21 comprise the HLU-611's Minor Alarm output. **The ALM option must be disabled (DIS) when using the Kentrox 220 T-Term shelf. This is required to resolve a conflict between the HLU alarm relay output and the Kentrox external equalizer output. Both use the same pins, 20 and 21.** These alarm contacts close for any of the following alarm conditions. Note that the front panel message which accompanies each alarm condition is shown in bold letters before each alarm condition. Since more than one alarm condition can exist at any given time but only one message can be displayed, the alarms are listed in their order of priorities. Only the highest priority alarm is displayed if more than one alarm condition exists.

- 1) **ALRM LOSW:** The VHDSL loop loses sync.
- 2) **ALRM LLOS:** Loss of the HLU T1 input signal.
- 3) **ALRM RLOS:** Loss of HRU T1 input signal.
- 4) **ALRM HES:** VHDSL Loop has exceeded the 24 hour user-selected Errored-Seconds (CRC) threshold.
- 5) **ALRM DS1:** The total number of bipolar violations (BPV) at the HLU and HRU T1 input have exceeded the 24 hour user-selected threshold.
- 6) **ALM MAL:** The margin on the VHDSL Loop has dropped below the minimum threshold value set by the dumb terminal MARGIN ALARM THRES; as described in Section 8.




Figure 3. DB-9 Pin-outs.

The HLU 611's STATUS LED flashes RED for the duration of a minor alarm condition. Alarms 4 and 5 can be inhibited by selecting NONE for the ESAL system option. See Section 8 for System Settings information. The MAL1 alarm can be disabled by setting the margin alarm threshold to 0. All six alarms can be inhibited by selecting DIS (disable) for the ALM system option. The MNALRM can be retired by executing the ACO option. This is accomplished by depressing the SEL button on the front panel. This turns the alarm off and replaces the ALRM message by the ACO message. The second part of the ALRM message, which defines the cause of the alarm, remains. Both messages remain until the alarm condition clears or another alarm occurs. Disabling the ALM also retires an ACO condition.

**7.18** Pin 32, FUSEALARM, is driven to -48 V through a 1000 ohm resistor and the front panel STATUS LED turns red whenever the on board fuse opens.

**7.19** The HLU-611's front panel tri-color STATUS LED has the following states:

- GREEN - Normal Operation
- FLASHING GREEN - VHDSL Acquisition
- FLASHING RED - Minor Alarm (For conditions see Paragraph 7.17)
- RED - FUSEALRM
- YELLOW - Self Test in process or an HLU loopback in effect (CREM or NLOC)
- FLASHING YELLOW - The HLU is in an ARMED state

**7.20** Depressing both the MODE and SEL pushbuttons on the front panel for at least three seconds initiates a MANUAL loopback session. This session allows the user to SEL one of four HiGain loopbacks. The message, MAN LPBK, appears on the front panel display followed by the message NRE?. If the SEL button is now depressed, an NREM loopback is executed and the message changes from NRE? to NREM. If the MODE button is depressed instead of the SEL button, NRE? is replaced by NLO?. This now allows an NLOC loopback to be executed with the SEL button. Depressing the MODE button two more times yields the CLO? (CLOC) and CRE? (CREM) customer loopback options. This interactive button procedure permits any of the four HiGain loopback to be executed. Once a loopback is executed, it

can be terminated and the next loopback option presented by depressing the MODE button. If neither button is depressed for a period of 30 seconds, this manual loopback session terminates and the normal margin displays reappear. If this time-out occurs with an active loopback in effect, the appropriate loopback message appears in addition to the loop margin messages. Once the manual loopback session terminates, the loopback remains in effect until it times-out in accordance with the user LBTO setting. It can also be terminated by re-entering the manual loopback mode and selecting another loopback. Only one loopback can exist at any given time. Depressing both buttons, again for three seconds, terminates any active loopback, ends the MANUAL loopback session and returns the display to normal.

## **8. OPTIONS**

**8.01** The HLU-611 contains a non-volatile RAM which stores the system option settings. No dip-switches or jumpers are required to set the HLU-611 configuration. The options are set via pushbuttons on the front panel, through the RS-232 interface, or from the NMA interface and are retained if shelf power is lost or if the HLU-611 is unplugged. Table 2 lists the HLU-611 option settings. Figure 8 illustrates the same options on the HLU-611 set-up menu. The settings shown in the second column represent the factory default settings. The third column values (in parenthesis) indicate the other parameter options.

**8.02** The SETUP (MODE and SEL) momentary pushbuttons are used to set the options from the front panel. To initiate an OPTION SETTING mode, depress the MODE button for one second and release. The message displayed on the front panel alternates between the system parameter and its current setting. Depressing the SEL button steps the display through all possible settings (one at a time) of the MODE (parameter) being displayed. After the desired setting has been chosen, depress MODE. This does two things. First it updates the current displayed mode to the setting chosen. It then selects the next configurable parameter. After the last parameter has been selected, the display shows CONF/NO. If the MODE button is now depressed, none of the changed parameters are installed. If the SEL button is depressed, a YES message is displayed and the chosen changes are installed. In either case the display returns to its normal mode. The display also

returns to its normal mode, without installing any new changes, if neither button is depressed for 30 seconds.

**8.03** All of the 12 user options can be set to the factory default values by depressing the SEL button for six seconds until the message: "DFLT NO" message is displayed. "DFLT YES" will be displayed indicating the factory default values are now in effect. To terminate the DFLT mode without setting the factory default values, press the MODE button or do nothing for 30 seconds. The latter returns the display to its normal state.

**8.04** Depressing the MODE button for three or more seconds causes the display to scroll through the HLU's software version number, its List #, the type of frame pattern being received from the DSX-1, the line code setting of the HLU and all 11 option settings. See Table 9 for these additional messages.

**8.05** The following three user options must be set with a dumb or smart terminal: CIRCUIT ID, DS0 BLOCKING and MARGIN ALARM THRESHOLD.

**8.06** The CIRCUIT ID option is set by choosing the "I" option from the dumb terminal's main menu shown in Figure 6. The message "enter circuit ID #: 24 characters max" follows the "I" selection hit the return key after entering the chosen set of alpha-numeric ID characters. Then chose "C" to confirm. Note if more than 24 characters are entered, an error message appears. Simply delete the excess characters and then hit the return key once again. The ID appears in all HLU screens as shown in Figures 7 through 13. The ID does not appear on the HRU screens when the maintenance port is accessed at the remote unit. Note that the Circuit ID is not set to its default (all blanks) setting when the DFLT setting option is utilized.

**8.07** To set the DS0 BLOCKING option first select the SYSTEMS SETTINGS ("D" choice) from the main menu. The menu shown in Figure 8 appears. Now enter the letter "B" shown in parenthesis of the DS0 blocking selection. The DS0 channels are blocked or unblocked by entering each channel's number. Multiple channels can be selected by inserting a space between each entry. After all the new settings have been made, enter "E" for exit and then "C" for confirm. The new choices are now installed. If DS0 blocking is invoked in a HiGain-2 system that has an earlier HRU that does not support the blocking option, blocking will only

occur at the DS1 output of the HLU. The HRU's DS1 output will not be blocked. Also, all blocked channels are opened for all HiGain-2 loopback tests. This allows the standard full bandwidth T1 loopback tests to be performed.

**8.08** To set the MARGIN ALARM THRESHOLD select "G" from the system settings menu. Enter the desired minimum acceptable alarm threshold from the 0 to 15 dB range. This causes a minor alarm to occur (see Paragraph 7.17) if the margin on the VHDSL loop drops below the selected threshold value. Since the margin can never drop below 0, choosing "0" for the margin threshold turns the margin alarm off.

**8.09** The other dumb terminal system settings are set in a similar manner. Simply enter the letter in parenthesis of the parameter to be changed. Each entry of this letter scrolls the parameter to its next value, hit the enter key after each selection is made after all selections have been made, enter "E" and then "C" to the resulting Confirm message. This activates the new choices and returns control to the main menu.

**8.10** The SELF-TEST mode that occurs when the VHDSL loop is not in sync includes the input DS1 transceiver chip in the self test procedure. This process can cause the AIS pattern, that is normally transmitted from the HLU during these out of sync intervals, to exhibit occasional BPVs.

**8.11** The DS1 line code option should always be set to conform to the type of DS1 service, AMI or B8ZS, being provided by the HiGain system. The AUTO mode, which can adapt to either AMI or B8ZS, should only be used in applications that require it (such as when HiGain acts as a standby circuit to DS1 circuits whose line codes are not known or may be both AMI and B8ZS) since it has the following two limitations. The AUTO mode will induce one BPV in the DS1 bit stream whenever it switches from AMI to B8ZS. The AUTO mode allows each HiGain end, HLU and HRU, to set its DS1 mode to the code it is receiving at its local DS1 input port. Thus if the line codes being received by HiGain are different in each of the two DS1 directions (unlikely, but possible) the HiGain DS1 output codes will not match their respective DS1 input codes at the other end. This could cause the customer's received data to be AMI instead of B8ZS and thus violate the one's density rules by having excessive zeros.



## 9. LOOPBACKS

**9.01** HiGain-2 has a family of loopback options.

The most important of these is the Smart-Jack loopback which enables the HRU-612 to respond to the standard 2/3 in 5 Smart-Jack in-band loopback codes. This option can be enabled or disabled from either the front panel settings or the dumb terminal system settings menu.

**9.02** In addition to the Smart-Jack loopback, HiGain-2 can be configured for one of five special in-band loopback command sequences. These are selected from the SPLB user option shown in Table 2 and Figure 8. The loopback locations are shown in Figure 5.

**9.03** GNLB is the HiGain-2 Generic loopback code. The GNLB allows 4 in 7 or 6 in 7 in-band codes to loop-up the HLU (NLOC or CREM respectively) and 3 in 7 or 4 in 7 in-band codes to loop-up the HRU (NREM or CLOC respectively). NLOC and NREM are issued from the HLU DS1 interface. CLOC and CREM are issued from the HRU DS1 interface. All looped states are terminated (looped-down) with the 3 in 5 loop-down code. All commands must be present for 5 seconds before HiGain-2 responds. Table 3 lists the test procedures that apply when using the GNLB mode.

**9.04** The A1LB loopback selection (Table 4) complies with that proposed for VHDSL systems in the T1E1.4/92 recommendation with the following additions:

- 1) Query loopback
- 2) IOR powerdown
- 3) Three loopback time-out choices
- 4) Initiation from either end
- 5) Repeating bit error signatures
- 6) Alternate Query loopback

These additions make A1LB identical to A2LB described below. It is given a separate identity to allow future T1E1 enhancements to be added without affecting A2LB.

**9.05** A2LB through A5LB are four special addressable repeater loopback functions which are supported by the List 6 version of HiGain-2. These loopbacks provide HiGain-2 with sophisticated maintenance and trouble shooting tools. Tables 5 through 8 list the details of these Special Loopback (SPLB) functions. A2LB and A5LB are patterned after the Teltrend addressable T1 repeater loopbacks. A3LB and A4LB are

patterned after the Wescom addressable T1 repeater loopbacks. All four SPLBs have been enhanced to handle the specific requirements of the following HiGain-2 customers:

- A2LB (Teltrend) = Southwestern Bell
- A3LB (Wescom) = New England Tel.
- A4LB (Wescom Mod 1) = New York Tel.
- A5LB (Teltrend Mod 1) = Southern New England Tel. (SNET)

**9.06** A5LB differs from A2LB in that A5LB does not block the arming (3 in 5) code from exiting the HLU into the network. A2LB can be configured to either block this arming code after two seconds, and replace it with the AIS code, or to unblock it by executing the FAR-END ACTIVATE code. Since A5LB never blocks the arming code from exiting the HLU, it does not need this FAR-END ACTIVATE code. A3LB differs from A4LB in that A3LB supports the additional 1 in 6 smart jack loopback command. Refer to the PairGain HiGain-2 Intelligent Repeater Application Note # 910 Part # 325-910-100 for more SPLB details.

**9.07** When T1 loopback tests are performed on the HiGain-2 system with metallic loopback connections at either end, the DS1 code that exists at the metallic loopback interface may be different from the DS1 code being received at the opposite end when the DS1 user code is set to AUTO. This is caused by the fact that in the AUTO DS1 code mode, the HLU and HRU set their own code independent of each other. Each end sets its transmit code to match its receive code. Thus if one end is receiving AMI and the other B8ZS, their codes are different. For example, if the HRU has a metallic loopback and the HLU's receive pattern's code is changed from AMI to B8ZS and then the all 0 pattern is sent into the HLU, the HLU changes to its B8ZS mode while the HRU remains in its AMI mode and thus loops all 0's. This causes the HRU to indicate a LOS condition which then causes the HLU to output the AIS pattern

**9.08** HiGain-2 may take longer than normal to respond to inband loopback commands when its framing mode is set to UNFR and the inband commands are sent in either an SF or ESF mode. The frame bits override the command bits and cause errors in the command sequence. These errors cause HiGain-2 to reject some sequences. This can extend the detection interval.

**C. INSTALLATION AND TEST**

**10. INSTALLATION**

**10.01** Upon receipt of the equipment, visually inspect it for signs of damage. If the equipment has been damaged in transit, immediately report the extent of damage to the transportation company and to PairGain.

**10.02** The HLU-611 mounts in a 220-configuration Office Repeater Bay (ORB) shelf or equivalent Small Cross Section Shelf (SXSS), Kentrox T-Term, Wescom 342-30 shelves, or PairGain HLS-410 (19") or HLS-419 (23"). The HLU-611 slot pin-outs are shown in Figure 4.

**11.02** The HLU's 4 character front panel display has many useful system diagnostic messages. They are listed in Table 9. This display turns on when power is initially applied to the 611. In order to conserve power, it only remains on for five minutes if neither the MODE nor SEL buttons are depressed. The use of either button restarts the five minute power-control timer.

**11.03** If trouble is encountered on the DSX-1 interface, verify that the hit is making a positive connection with the mounting assembly's connector. Also, verify that the pre-equalizer is properly set. All installations should be set to the largest value that does not exceed the distance from the DSX-1 to the shelf.

**CAUTION**

The ALM option must be disabled (DIS) when using the Kentrox 220 T-Term shelf. This is required to resolve a conflict between the HLU alarm relay output and the Kentrox external equalizer output. Both use the same pins, 20 and 21.

The HLU 611 is incompatible with the newer Kentrox 224 shelves when these shelves are optioned to connect their -V line (which is normally -48 V) to -130 V. The -V line connects to pin 40, while the HLU-231 connects both pins 39 and 40 to the -48 V line. The HLU-611 is also incompatible with the older AT and T ORB shelves (such as the 3 C757-30G1A, SD 3C3710-01) that have not been modified for ASPR (Automatic Span Powering Repeater) type T1 office repeater applications. These older bays connect the -130 V shelf power bus to pin 40 which conflicts with the HLU-611 which connects pin 40 to -48 V.

**11. TESTING**

**11.01** Tables 3 through 8 provide step by step test procedures for the HLU-611 Unit as a function of the loopback option selected. These procedures allow verification of the integrity of the VHDSL channel to the HRU-612 remote unit as well as the DS1 channels to the customer and the local DSX-1 interface.





Figure 4. HLU-611 Pin-outs.

**11.04** The transmit and receive T1 DSX-1 ports have splitting access and bridging miniature 210 jacks as shown in Figure 2. Connecting one cable between the two BDG jacks and another between the two SPAN jacks splits the XMT and RCV and creates metallic loopbacks towards both the DSX-1 and the HLU.

**11.05** Figure 7 shows the HLU status screen. It contains useful information on the VHDSL loops and the DS1 input. Figures 11, 12 and 13

show the performance data and alarm history screens. All the performance data shown in Figures 8, 11 and 12 can be cleared to zero by selecting the (C)lear option from the HLU Status Screen shown in Figure 7. Note that since the HLU is considered the master module, this clears **all** performance data screens at both the HLU and the HRU. Clearing the data from the HRU only clears performance data at the HRU. It does not clear it at the HLU.



**Figure 5. HLU-611 Loopback Configurations.**

**TABLE 2. SYSTEM OPTION SETTINGS**

<b>MODE</b>	<b>CHOICE</b>	<b>DESCRIPTION</b>
EQL	EXT*	Replaces the internal equalizer with a 12 Vpk-pk drive source for an external equalizer.
	0	Sets the Equalizer to DSX-1 for 0-133 feet.
	133	Sets the Equalizer to DSX-1 for 133-266 feet.
	266	Sets the Equalizer to DSX-1 for 266-399 feet.
	399	Sets the Equalizer to DSX-1 for 399-533 feet.
	533	Sets the Equalizer to DSX-1 for 533-655 feet.
LBPK	DIS	Configures the HiGain system to ignore all in-band Smart-Jack loopback commands.
	ENA*	Enables the HiGain system to recognize all in-band Smart-Jack loopback commands.
SPLB	GNLB*	Configures the HiGain system to respond to the generic (3/4 in 7) in-band loopback codes.
	A1LB and A2LB	Configures the HiGain system to respond to the Teltrend addressable repeater in-band loopback codes.
	A3LB	Configures the HiGain system to respond to the Wescom addressable repeater in-band loopback codes.
	A4LB	Configures the HiGain system to respond to the Wescom Mod 1 addressable repeater in-band loopback codes.
	A5LB	Configures the HiGain system to respond to the Teltrend Mod 1 addressable repeater in-band loopback codes.
PWRF	DIS	Disables powering to the HRU-412.
	ENA*	Enables powering to the HRU-412.
ZBTS	ON	Tells the HiGain system that the ESF frame is operating in its Zero Byte Time Slot Interface (ZBTSI) mode.
	OFF*	Tells the HiGain system that the ESF frame is operating in its normal non-ZBTSI mode.
ESAL	17	Creates a minor alarm condition which flashes the red STATUS LED when 17 Errored Seconds (ES) (17 HDSL CRC errors on either HDSL loop or a total of 17 BPV and FERR occur within a 24-hour period.
	170	Creates a minor alarm condition which flashes the red STATUS LED when 170 ES (170 HDSL cyclic redundancy check (CRC) errors on either HDSL loop or a total of 170 BPV) occur within a 24-hour period.
	NONE*	Prevents generation of a minor alarm due to excessive Errored Seconds.
LBTO	NONE	Disables automatic time-out cancellation of all loopbacks.
	20	Sets automatic cancellation of all loopbacks to 20 minutes after initiation.
	60*	Sets automatic cancellation of all loopback to 60 minutes after initiation.
	120	Sets automatic cancellation of all loopback to 120 minutes after initiation.

*Table continued on next page*

**TABLE 2. SYSTEM OPTION SETTINGS (CONTINUED)**

<i>MODE</i>	<i>CHOICE</i>	<i>DESCRIPTION</i>
ALM	DIS*	Opens the minor alarm relay contacts if closed, and prevents another relay alarm closure from occurring.
	ENA	Enables activation of the minor alarm relay when a minor alarm condition occurs.
DS1	AUTO	The HLU-611 and HRU-612 independently monitor their incoming DS1 bit streams for the Binary Eight Zero Substitution (B8ZS) pattern. If either unit detects this pattern, it enters its B8ZS mode. It reverts back to its Alternate Mark Inversion (AMI) mode if no B8ZS patterns are received for five seconds.
	B8ZS	Places both the HLU-611 and HRU-612 into their B8ZS modes.
	AMI*	Places both the HLU-611 and HRU-612 into their AMI modes.
FRMG	AUTO*	Configures the HiGain system to operate in an auto-framing (AUTO) mode in which it continuously searches the input T1 bit stream for a valid SF or ESF frame pattern. This feature is required for fractional T1 applications (DS0 blocking) where it insures proper channel time slot alignment. While the HiGain system can also process unframed data in this AUTO mode, it is recommended that the unframed (UNFR) mode be used for all unframed applications. Using the AUTO mode for unframed applications runs the risk of detecting "pseudo-valid" frame sequences, which can affect the data integrity.
	UNFR	Configures the HiGain system to operate in an unframed mode. This mode disables the auto framing process and forces the HiGain system to function as a transparent bit pipe.
HAIS	2LP*	Causes the HiGain system to transmit the AIS signal at both the HLU-611 and HRU-612 T1 output ports when both of the HDSL loops are not in sync (LOSW).
	1LP	Causes the HiGain system to transmit the AIS signal at both the HLU-611 and HRU-612 T1 output ports when either of the two HDSL loops is not in sync (LOSW) or if a MARGin alarm occurs.
SAIS	ENA*	Causes the HRU-612 to transmit the AIS signal towards the Network Interface (NI) when in NREM or Smart-Jack loopback.
	DIS	Causes the List 1 HRU-612 to transmit the signal from the network towards the NI and the List 2 HRU-612 to open and terminate its RCV NI port when an HRU NREM or Smart-Jack loopback is executed. The AIS signal is off.
CONF	YES	Confirms that all eleven (listed above) operating modes are to be updated to their current choices.
	NO*	Prevents the most recently selected operating mode choices from being updated. They remain as they were before the system option settings mode was entered.
MARGin Alarm Trsh	0 to 15 dB	The Margin Alarm Threshold can only be set via the RS-232 maintenance port with a terminal. It determines the minimum allowable margin below which a minor alarm can occur.
	4 dB*	(Default value)
DS0	BLK	The DS0 blocking option can only be set via the RS-232 maintenance port with a terminal. The 4-Character HLU-611 front panel only displays the status of the blocking option. BLK indicates at least one channel is blocked.
	NONE*	NONE indicates no channels are blocked.

\*Indicates HLU-611 factory (default) settings.

**TABLE 3. HLU-611 TEST PROCEDURES FOR GNLB OPTION**

Step	Action
1	Have the C.O. tester send the HRU (3 in 7) in-band loop-up code for five seconds. Observe that the HLU displays the "NREM" message indicating an HRU loopback is in effect (see Figure 5).
2	Have the C.O. tester transmit a T1 test signal into the HLU and verify that the returned (looped) signal is error free.
3	If the above test fails, have the C.O. tester transmit the (3 in 5) in-band loop-down code. Verify that the HLU display returns to normal.
4	Have the C.O. tester send the HLU (4 in 7) in-band loop-up for five seconds. Observe that the HLU displays the "NLOC" message indicating an HLU loopback is in effect.
5	Repeat step "2". If the test passes, the problem is in the cable pair or the HRU. If it fails, the problem is in the C.O. equipment.
6	The NREM, NLOC, CREM and CLOC loopbacks can also be initiated from the front panel of the HLU with the MODE and SEL pushbuttons. See Paragraph 7.21 for details.
7	The HLU can be looped-up from the remote location (CREM) by issuing the 6 in 7 command at the HRU's DS1 input port.
8	The HRU can be looped-up from the remote location (CLOC) by issuing the 5 in 7 command at the HRU's DS1 input port.

**TABLE 4. HLU-611 TEST PROCEDURES FOR A1LB OPTION**

Step	Action
1	Send into the HLU the inband ARMING and NIU (Network Interface Hit) LPBK code 11000 for at least five seconds, or at least four repetitions of the 16 bit ESF Data Link ARMING code 0001 0010 1111 1111.
2	Monitor the output of the HLU-611 for the return of the pattern. Return of pattern indicates that either the HRU has looped-up (if the SMART-JACK LOOPBACK option is ENABLED) or that an external NIU has looped up (if the SMART-JACK LOOPBACK option is DISABLED) and that the HLU and HRU units have been ARMED. Verify that the HLU display intermittently indicates "ARM" and also "SMJK" if the HRU is in loopback. Also verify, if possible, that the LOOPBACK LED of the HRU-612 is flashing, indicating that the HRU is armed or that it is on solid, indicating that it is both armed and in loopback.
3	<p>Once armed, the HLU can be looped back (NLOC in Figure 5) by sending IOR (Intelligent Office Repeater) LPBK activation code 1101 0011 1101 0011 for at least five seconds. The tester observes the following activation response:</p> <ul style="list-style-type: none"> <li>• two seconds of AIS (all ones), followed by:</li> <li>• five seconds of returning data pattern, followed by:</li> <li>• 231 logic errors (including the frame bits) occur in the returned pattern (20 errors if ILR-2 were sent), followed by normal looped data. Note that this error pattern will repeat every 20 seconds as long as the IOR loopback pattern is being sent. This same 20 second repeat scenario also applies to the different bit error signatures generated by the ILR, Time-Out Override and Query commands. Only 230 bit errors may be detected if the test set does not include frame errors in its bit error count.</li> </ul> <p>The HiGain-2 Line Hit is now in Logic Loopback (NLOC of Figure 5). The display on the HLU-611 periodically shows NLOC (network local loop) and ARM (the HLU is still armed) in addition to the margin displays. The Loopback Time-out option, which is user settable to NONE, 20, 60 or 120 minutes, determines the duration of this loopback unless it is overridden by the TIME-OUT OVERRIDE command or a loop down command is sent. If the Time-out Override code 1101 0101 1101 0110 is received, the activation response sequence described above is repeated and the automatic timed expiration of the loopback is inhibited. If this Time-out Override is sent, then the only way to loop the HLU down is to issue the IR (Intelligent Repeater) LPDN (loopdown) code 1001 0011 1001 0011 or to issue the NIU (Network Interface Hit) LPDN and Disarm code 11100. The automatic time-out timer is restored during subsequent loopback sessions. The loopback time out timer is reset to 20, 60 or 120 minutes when any of the loopback commands, except Time Out Override, are sent.</p>
4	Upon completion, the tester sends IOR LPDN code 1001 0011 1001 0011 to loop-down the HiGain-2 Line Hit. The unit remains armed however, as indicated by the ARM message on the HLU-611 and the flashing of the HRU-612's LOOPBACK LED.

*Table continued on next page*

**TABLE 4. HLU-611 TEST PROCEDURES FOR A1LB OPTION (CONTINUED)**

Step	Action																																				
5	<p>Using the following codes, a network tester can activate loopbacks NLOC or NREM or SMJK (if enabled) shown in Figure 5. A customer tester can activate loopbacks CLOC or CREM.</p> <p style="text-align: center;"><b>Addressable 1 (A1LB) Repeater Loopback Commands</b></p> <table border="0" style="width: 100%;"> <tr> <td style="width: 35%;">ARMING or NIU LPBK (inband)</td> <td style="width: 30%;">Arming code</td> <td style="width: 35%;">11000 11000...</td> </tr> <tr> <td>ARMING or NIU LPBK (ESF Data Link)</td> <td>Arming code</td> <td>1111(F)*1111(F)0100(4)1000(8)</td> </tr> <tr> <td>IR LPDN or DISARM (inband)</td> <td>Disarming code</td> <td>11100 11100...</td> </tr> <tr> <td>DISARM (ESF Data Link)</td> <td>Disarming code</td> <td>1111(F)1111(F)0010(2)0100(4)</td> </tr> <tr> <td>IOR LPBK (NLOC and CREM 231 errors)</td> <td>HLU Loop up</td> <td>1101(D)0011(3)1101(D)0011(3)</td> </tr> <tr> <td>ILR-2 LPBK (NREM and NLOC 20 bit errors)</td> <td>HRU Loop up</td> <td>1100(C)0111(7)0100(4)0010(2)</td> </tr> <tr> <td>IR LPDN</td> <td>Loop down (HLU or HRU)</td> <td>1001(9)0011(3)1001(9)0011(3)</td> </tr> <tr> <td>IR QUERY LPBK</td> <td>Query loopback</td> <td>1101(D)0101(5)1101(D)0101(5)</td> </tr> <tr> <td>IR ALTERNATE QUERY LPBK</td> <td>Alternate Query loopback</td> <td>1101(D)0101(5)1110(E)1010(A)</td> </tr> <tr> <td>TIME-OUT OVERRIDE</td> <td>Loopback Time-out Override</td> <td>1101(D)0101(5)1101(D)0110(6)</td> </tr> <tr> <td>FAR END NIU ACTIVATE</td> <td>Unblock AIS and pass 2 in 5</td> <td>1100(C)0101(5)0101(5)0100(4)</td> </tr> <tr> <td>IOR POWER DOWN (HLU)</td> <td>Removes VHDSL line power</td> <td>0110(6)0111(7)0110(6)0111(7)</td> </tr> </table> <p>Note: The left most bit arrives first in all sequences. The detection algorithm functions reliably with a random 10E-3 bit error ratio (BER) on the facility. The IOR POWER DOWN code must remain present for the duration of the power down mode. When this code is removed, HiGain-2 returns to its normal unlooped and unarmed state. *This is the HEX number for the 4 bit group.</p>	ARMING or NIU LPBK (inband)	Arming code	11000 11000...	ARMING or NIU LPBK (ESF Data Link)	Arming code	1111(F)*1111(F)0100(4)1000(8)	IR LPDN or DISARM (inband)	Disarming code	11100 11100...	DISARM (ESF Data Link)	Disarming code	1111(F)1111(F)0010(2)0100(4)	IOR LPBK (NLOC and CREM 231 errors)	HLU Loop up	1101(D)0011(3)1101(D)0011(3)	ILR-2 LPBK (NREM and NLOC 20 bit errors)	HRU Loop up	1100(C)0111(7)0100(4)0010(2)	IR LPDN	Loop down (HLU or HRU)	1001(9)0011(3)1001(9)0011(3)	IR QUERY LPBK	Query loopback	1101(D)0101(5)1101(D)0101(5)	IR ALTERNATE QUERY LPBK	Alternate Query loopback	1101(D)0101(5)1110(E)1010(A)	TIME-OUT OVERRIDE	Loopback Time-out Override	1101(D)0101(5)1101(D)0110(6)	FAR END NIU ACTIVATE	Unblock AIS and pass 2 in 5	1100(C)0101(5)0101(5)0100(4)	IOR POWER DOWN (HLU)	Removes VHDSL line power	0110(6)0111(7)0110(6)0111(7)
ARMING or NIU LPBK (inband)	Arming code	11000 11000...																																			
ARMING or NIU LPBK (ESF Data Link)	Arming code	1111(F)*1111(F)0100(4)1000(8)																																			
IR LPDN or DISARM (inband)	Disarming code	11100 11100...																																			
DISARM (ESF Data Link)	Disarming code	1111(F)1111(F)0010(2)0100(4)																																			
IOR LPBK (NLOC and CREM 231 errors)	HLU Loop up	1101(D)0011(3)1101(D)0011(3)																																			
ILR-2 LPBK (NREM and NLOC 20 bit errors)	HRU Loop up	1100(C)0111(7)0100(4)0010(2)																																			
IR LPDN	Loop down (HLU or HRU)	1001(9)0011(3)1001(9)0011(3)																																			
IR QUERY LPBK	Query loopback	1101(D)0101(5)1101(D)0101(5)																																			
IR ALTERNATE QUERY LPBK	Alternate Query loopback	1101(D)0101(5)1110(E)1010(A)																																			
TIME-OUT OVERRIDE	Loopback Time-out Override	1101(D)0101(5)1101(D)0110(6)																																			
FAR END NIU ACTIVATE	Unblock AIS and pass 2 in 5	1100(C)0101(5)0101(5)0100(4)																																			
IOR POWER DOWN (HLU)	Removes VHDSL line power	0110(6)0111(7)0110(6)0111(7)																																			
6	<p>After testing is complete, send the universal loopdown [IR (Intelligent Repeater) LPDN] code if the system is to loopdown but remain ARMED. Send the disarm code 11100 if all the equipment is to be looped down, disarmed and returned to normal operation. Note that the ARMED mode has an automatic time-out of 120 minutes.</p>																																				
7	<p>The NREM, NLOC, CREM and CLOC loopbacks can also be initiated from the front panel of the HLU with the MODE and SEL pushbuttons. See Paragraph 7.20 for details.</p>																																				



**TABLE 5. HLU-611 TEST PROCEDURES FOR A2LB OPTION**

Step	Action
1	Send into the HLU the inband ARMING and NIU (Network Interface Hit) LPBK code 11000 for at least five seconds, or at least four repetitions of the 16 bit ESF Data Link ARMING code 0001 0010 1111 1111.
2	Monitor the output of the HLU-611 for the return of the pattern. Return of pattern indicates that either the HRU has looped-up (if the SMART-JACK LOOPBACK option is ENABLED) or that an external NIU has looped up (if the SMART-JACK LOOPBACK option is DISABLED) and that the HLU and HRU units have been ARMED. Verify that the HLU display intermittently indicates "ARM" and also "SMJK" if the HRU is in loopback. Also verify, if possible, that the LOOPBACK LED of the HRU-612 is flashing, indicating that the HRU is armed or that it is on solid, indicating that it is both armed and in loopback.
3	<p>Once armed, the HLU can be looped back (NLOC in Figure 5) by sending IOR (Intelligent Office Repeater) LPBK activation code 1101 0011 1101 0011 for at least five seconds. The tester observes the following activation response:</p> <ul style="list-style-type: none"> <li>• two seconds of AIS (all ones), followed by:</li> <li>• five seconds of returning data pattern, followed by:</li> <li>• 231 logic errors (including the frame bits) occur in the returned pattern (20 errors if ILR-2 were sent), followed by normal looped data. Note that this error pattern will repeat every 20 seconds as long as the IOR loopback pattern is being sent. This same 20 second repeat scenario also applies to the different bit error signatures generated by the ILR, Time-Out Override and Query commands. Only 230 bit errors may be detected if the test set does not include frame errors in its bit error count.</li> </ul> <p>The HiGain-2 Line Hit is now in Logic Loopback (NLOC of Figure 5). The display on the HLU-611 periodically shows NLOC (network local loop) and ARM (the HLU is still armed) in addition to the margin displays. The Loopback Time-out option, which is user settable to NONE, 20, 60 or 120 minutes, determines the duration of this loopback unless it is overridden by the TIME-OUT OVERRIDE command or a loop down command is sent. If the Time-out Override code 1101 0101 1101 0110 is received, the activation response sequence described above is repeated and the automatic timed expiration of the loopback is inhibited. If this Time-out Override is sent, then the only way to loop the HLU down is to issue the IR (Intelligent Repeater) LPDN (loopdown) code 1001 0011 1001 0011 or to issue the NIU (Network Interface Hit) LPDN and Disarm code 11100. The automatic time-out timer is restored during subsequent loopback sessions. The loopback time-out timer is reset to 20, 60, or 120 minutes when any of the loopback commands, except Time Out Override, are sent.</p>
4	Upon completion, the tester sends IOR LPDN code 1001 0011 1001 0011 to loop-down the HiGain-2 Line Hit. The unit remains armed, however, as indicated by the ARM message on the HLU-611 and the flashing of the HRU-612's LOOPBACK LED.

*Table continued on next page*

**TABLE 5. HLU-611 TEST PROCEDURES FOR A2LB OPTION (CONTINUED)**

Step	Action																																				
5	<p>Using the following codes, a network tester can activate loopbacks NLOC or NREM or SMJK (if enabled) shown in Figure 5. A customer tester can activate loopbacks CLOC or CREM.</p> <p style="text-align: center;"><b>Addressable 2 (A2LB) Repeater Loopback Commands</b></p> <table border="0"> <tr> <td>ARMING or NIU LPBK (inband)</td> <td>Arming code</td> <td>11000 11000...</td> </tr> <tr> <td>ARMING or NIU LPBK (ESF Data Link)</td> <td>Arming code</td> <td>1111(F)*1111(F)0100(4)1000(8)</td> </tr> <tr> <td>IR LPDN or DISARM (inband)</td> <td>Disarming code</td> <td>11100 11100...</td> </tr> <tr> <td>DISARM (ESF Data Link)</td> <td>Disarming code</td> <td>1111(F)1111(F)0010(2)0100(4)</td> </tr> <tr> <td>IOR LPBK (NLOC and CREM 231 errors)</td> <td>HLU Loop up</td> <td>1101(D)0011(3)1101(D)0011(3)</td> </tr> <tr> <td>ILR-2 LPBK (NREM and NLOC 20 bit errors)</td> <td>HRU Loop up</td> <td>1100(C)0111(7)0100(4)0010(2)</td> </tr> <tr> <td>IR LPDN</td> <td>Loop down (HLU or HRU)</td> <td>1001(9)0011(3)1001(9)0011(3)</td> </tr> <tr> <td>IR QUERY LPBK</td> <td>Query loopback</td> <td>1101(D)0101(5)1101(D)0101(5)</td> </tr> <tr> <td>IR ALTERNATE QUERY LPBK</td> <td>Alternate Query loopback</td> <td>1101(D)0101(5)1110(E)1010(A)</td> </tr> <tr> <td>TIME-OUT OVERRIDE</td> <td>Loopback Time-out Override</td> <td>1101(D)0101(5)1101(D)0110(6)</td> </tr> <tr> <td>FAR END NIU ACTIVATE</td> <td>Unblock AIS and pass 2 in 5</td> <td>1100(C)0101(5)0101(5)0100(4)</td> </tr> <tr> <td>IOR POWER DOWN (HLU)</td> <td>Removes VHDSL line power</td> <td>0110(6)0111(7)0110(6)0111(7)</td> </tr> </table> <p>Note: The left most bit arrives first in all sequences. The detection algorithm functions reliably with a random 10E-3 bit error ratio (BER) on the facility. The IOR POWER DOWN code must remain present for the duration of the power down mode. When this code is removed, HiGain-2 returns to its normal unlooped and unarmed state. *This is the HEX number for the 4 bit group.</p>	ARMING or NIU LPBK (inband)	Arming code	11000 11000...	ARMING or NIU LPBK (ESF Data Link)	Arming code	1111(F)*1111(F)0100(4)1000(8)	IR LPDN or DISARM (inband)	Disarming code	11100 11100...	DISARM (ESF Data Link)	Disarming code	1111(F)1111(F)0010(2)0100(4)	IOR LPBK (NLOC and CREM 231 errors)	HLU Loop up	1101(D)0011(3)1101(D)0011(3)	ILR-2 LPBK (NREM and NLOC 20 bit errors)	HRU Loop up	1100(C)0111(7)0100(4)0010(2)	IR LPDN	Loop down (HLU or HRU)	1001(9)0011(3)1001(9)0011(3)	IR QUERY LPBK	Query loopback	1101(D)0101(5)1101(D)0101(5)	IR ALTERNATE QUERY LPBK	Alternate Query loopback	1101(D)0101(5)1110(E)1010(A)	TIME-OUT OVERRIDE	Loopback Time-out Override	1101(D)0101(5)1101(D)0110(6)	FAR END NIU ACTIVATE	Unblock AIS and pass 2 in 5	1100(C)0101(5)0101(5)0100(4)	IOR POWER DOWN (HLU)	Removes VHDSL line power	0110(6)0111(7)0110(6)0111(7)
ARMING or NIU LPBK (inband)	Arming code	11000 11000...																																			
ARMING or NIU LPBK (ESF Data Link)	Arming code	1111(F)*1111(F)0100(4)1000(8)																																			
IR LPDN or DISARM (inband)	Disarming code	11100 11100...																																			
DISARM (ESF Data Link)	Disarming code	1111(F)1111(F)0010(2)0100(4)																																			
IOR LPBK (NLOC and CREM 231 errors)	HLU Loop up	1101(D)0011(3)1101(D)0011(3)																																			
ILR-2 LPBK (NREM and NLOC 20 bit errors)	HRU Loop up	1100(C)0111(7)0100(4)0010(2)																																			
IR LPDN	Loop down (HLU or HRU)	1001(9)0011(3)1001(9)0011(3)																																			
IR QUERY LPBK	Query loopback	1101(D)0101(5)1101(D)0101(5)																																			
IR ALTERNATE QUERY LPBK	Alternate Query loopback	1101(D)0101(5)1110(E)1010(A)																																			
TIME-OUT OVERRIDE	Loopback Time-out Override	1101(D)0101(5)1101(D)0110(6)																																			
FAR END NIU ACTIVATE	Unblock AIS and pass 2 in 5	1100(C)0101(5)0101(5)0100(4)																																			
IOR POWER DOWN (HLU)	Removes VHDSL line power	0110(6)0111(7)0110(6)0111(7)																																			
6	<p>After testing is complete, send the universal loopdown [IR (Intelligent Repeater) LPDN] code if the system is to loopdown but remain ARMED. Send the disarm code 11100 if all the equipment is to be looped down, disarmed and returned to normal operation. Note that the ARMED mode has an automatic time-out of 120 minutes.</p>																																				
7	<p>The NREM, NLOC, CREM and CLOC loopbacks can also be initiated from the front panel of the HLU with the MODE and SEL pushbuttons. See Paragraph 7.20 for details.</p>																																				

**TABLE 6. HLU-611 TEST PROCEDURES FOR A3LB OPTION**

Step	Action																																	
1	<p>The HiGain-2 Line Hit can be looped back (NLOC in Figure 5) by sending the (Addressable Office Repeater) LPBK activation code 1111(F) 1111(F) 0001(1) 1110(E) for at least five seconds. This causes the HLU to enter its NLOC state shown in Figure 5. The display on the HLU-611 alternates between NLOC (network local loop) and the margin displays. The Loopback Time-out option, which is user settable to NONE, 20, 60 or 120 minutes, determines the duration of this loopback unless it is overridden by the reception of a second identical 16 bit loopup command before the timer expires. When this time-out override state exists, the only way to loop the HLU down is to issue one of the three loopdown commands listed in Step 2. The automatic time-out mode is restored during subsequent loopback sessions.</p>																																	
2	<p>The following list summarizes the codes required to execute all the HiGain-2 loopbacks shown in Figure 5. Note that all code sequences must be present for at least five seconds.</p> <p>LU=LOOPUP, LD =LOOPDOWN, NI = NETWORK INTERFACE, CI = CUSTOMER INTERFACE.</p> <p style="text-align: center;"><b>Addressable 3 (A3LB) Repeater Loopback Commands</b></p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: center;"><u>POSITION</u></th> <th style="text-align: center;"><u>NAME</u></th> <th style="text-align: center;"><u>CODE</u></th> </tr> </thead> <tbody> <tr> <td>HLU-611 LU FROM NI</td> <td>NLOC</td> <td>1111(F)*1111(F)0001(1)1110(E)</td> </tr> <tr> <td>HLU-611 LU FROM CI</td> <td>CREM</td> <td>0011(3)1111(F)0001(1)1110(E)</td> </tr> <tr> <td>HRU-612 LU FROM NI</td> <td>NREM</td> <td>1111(F)1111(F)0000(0)0010(2)</td> </tr> <tr> <td>HRU-612 LU FROM CI</td> <td>CLOC</td> <td>0011(3)1111(F)0000(0)0010(2)</td> </tr> <tr> <td>HRU-612 LU FROM NI</td> <td>SMJK</td> <td>11000 11000 11000...</td> </tr> <tr> <td>HRU-612 LU FROM NI</td> <td>SMJK</td> <td>100000 100000 100000...</td> </tr> <tr> <td>HRU-612 LU FROM NI (ESF-DL)</td> <td>SMJK</td> <td>1111(F)1111(F)0100(4)1000(8)</td> </tr> <tr> <td>HLU and HRU LD FROM NI OR CI</td> <td></td> <td>11100 11100 11100...</td> </tr> <tr> <td>HLU and HRU LD FROM NI OR CI</td> <td></td> <td>100 100 100...</td> </tr> <tr> <td>HLU and HRU LD FROM NI OR CI(ESF-DL)</td> <td></td> <td>1111(F)1111(F)0010(2)0100(4)</td> </tr> </tbody> </table> <p>Note: the left most bit arrives first in all sequences. The detection algorithm functions reliably with a random 10E-3 bit error ratio (BER) on the facility. *This is the HEX number for the 4 bit group.</p>	<u>POSITION</u>	<u>NAME</u>	<u>CODE</u>	HLU-611 LU FROM NI	NLOC	1111(F)*1111(F)0001(1)1110(E)	HLU-611 LU FROM CI	CREM	0011(3)1111(F)0001(1)1110(E)	HRU-612 LU FROM NI	NREM	1111(F)1111(F)0000(0)0010(2)	HRU-612 LU FROM CI	CLOC	0011(3)1111(F)0000(0)0010(2)	HRU-612 LU FROM NI	SMJK	11000 11000 11000...	HRU-612 LU FROM NI	SMJK	100000 100000 100000...	HRU-612 LU FROM NI (ESF-DL)	SMJK	1111(F)1111(F)0100(4)1000(8)	HLU and HRU LD FROM NI OR CI		11100 11100 11100...	HLU and HRU LD FROM NI OR CI		100 100 100...	HLU and HRU LD FROM NI OR CI(ESF-DL)		1111(F)1111(F)0010(2)0100(4)
<u>POSITION</u>	<u>NAME</u>	<u>CODE</u>																																
HLU-611 LU FROM NI	NLOC	1111(F)*1111(F)0001(1)1110(E)																																
HLU-611 LU FROM CI	CREM	0011(3)1111(F)0001(1)1110(E)																																
HRU-612 LU FROM NI	NREM	1111(F)1111(F)0000(0)0010(2)																																
HRU-612 LU FROM CI	CLOC	0011(3)1111(F)0000(0)0010(2)																																
HRU-612 LU FROM NI	SMJK	11000 11000 11000...																																
HRU-612 LU FROM NI	SMJK	100000 100000 100000...																																
HRU-612 LU FROM NI (ESF-DL)	SMJK	1111(F)1111(F)0100(4)1000(8)																																
HLU and HRU LD FROM NI OR CI		11100 11100 11100...																																
HLU and HRU LD FROM NI OR CI		100 100 100...																																
HLU and HRU LD FROM NI OR CI(ESF-DL)		1111(F)1111(F)0010(2)0100(4)																																
3	<p>The NREM, NLOC, CREM and CLOC loopbacks can also be initiated from the front panel of the HLU with the MODE and SEL pushbuttons. See Paragraph 7.20 for details.</p>																																	

**TABLE 7. HLU-611 TEST PROCEDURES FOR A4LB OPTION**

Step	Action																														
1	<p>The HiGain-2 Line Hit can be looped back (NLOC in Figure 5) by sending the (Addressable Office Repeater) LPBK activation code 1111(F) 1111(F) 0001(1) 1110(E) for at least five seconds. This causes the HLU to enter its NLOC state shown in Figure 5. The display on the HLU-611 alternates between NLOC (network local loop) and the margin displays. The Loopback Time-out option, which is user settable to NONE, 20, 60 or 120 minutes, determines the duration of this loopback unless it is overridden by the reception of a second identical 16 bit loopup command before the timer expires. When this time-out override state exists, the only way to loop the HLU down is to issue one of the three loopdown commands listed in Step 2. The automatic time-out mode is restored during subsequent loopback sessions.</p>																														
2	<p>The following list summarizes the codes required to execute all the HiGain-2 loopbacks shown in Figure 5. Note that all code sequences must be present for at least five seconds.</p> <p>LU=LOOPUP, LD =LOOPDOWN, NI = NETWORK INTERFACE, CI = CUSTOMER INTERFACE.</p> <p style="text-align: center;"><b>Addressable 4 (A4LB) Repeater Loopback Commands</b></p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: center;"><u>POSITION</u></th> <th style="text-align: center;"><u>NAME</u></th> <th style="text-align: center;"><u>CODE</u></th> </tr> </thead> <tbody> <tr> <td>HLU-611 LU FROM NI</td> <td>NLOC</td> <td>1111(F)*1111(F)0001(1)1110(E)</td> </tr> <tr> <td>HLU-611 LU FROM CI</td> <td>CREM</td> <td>0011(3)1111(F)0001(1)1110(E)</td> </tr> <tr> <td>HRU-612 LU FROM NI</td> <td>NREM</td> <td>1111(F)1111(F)0000(0)0010(2)</td> </tr> <tr> <td>HRU-612 LU FROM CI</td> <td>CLOC</td> <td>0011(3)1111(F)0000(0)0010(2)</td> </tr> <tr> <td>HRU-612 LU FROM NI</td> <td>SMJK</td> <td>11000 11000 11000..</td> </tr> <tr> <td>HRU-612 LU FROM NI (ESF-DL)</td> <td>SMJK</td> <td>1111(F)1111(F)0100(4)1000(8)</td> </tr> <tr> <td>HLU and HRU LD FROM NI OR CI</td> <td></td> <td>11100 11100 11100....</td> </tr> <tr> <td>HLU and HRU LD FROM NI OR CI</td> <td></td> <td>100 100 100 ...</td> </tr> <tr> <td>HLU and HRU LD FROM NI OR CI(ESF-DL)</td> <td></td> <td>1111(F)1111(F)0010(2)0100(4)</td> </tr> </tbody> </table> <p>Note: the left most bit arrives first in all sequences. The detection algorithm functions reliably with a random 10E-3 bit error ratio (BER) on the facility. *This is the HEX number for the 4 bit group.</p>	<u>POSITION</u>	<u>NAME</u>	<u>CODE</u>	HLU-611 LU FROM NI	NLOC	1111(F)*1111(F)0001(1)1110(E)	HLU-611 LU FROM CI	CREM	0011(3)1111(F)0001(1)1110(E)	HRU-612 LU FROM NI	NREM	1111(F)1111(F)0000(0)0010(2)	HRU-612 LU FROM CI	CLOC	0011(3)1111(F)0000(0)0010(2)	HRU-612 LU FROM NI	SMJK	11000 11000 11000..	HRU-612 LU FROM NI (ESF-DL)	SMJK	1111(F)1111(F)0100(4)1000(8)	HLU and HRU LD FROM NI OR CI		11100 11100 11100....	HLU and HRU LD FROM NI OR CI		100 100 100 ...	HLU and HRU LD FROM NI OR CI(ESF-DL)		1111(F)1111(F)0010(2)0100(4)
<u>POSITION</u>	<u>NAME</u>	<u>CODE</u>																													
HLU-611 LU FROM NI	NLOC	1111(F)*1111(F)0001(1)1110(E)																													
HLU-611 LU FROM CI	CREM	0011(3)1111(F)0001(1)1110(E)																													
HRU-612 LU FROM NI	NREM	1111(F)1111(F)0000(0)0010(2)																													
HRU-612 LU FROM CI	CLOC	0011(3)1111(F)0000(0)0010(2)																													
HRU-612 LU FROM NI	SMJK	11000 11000 11000..																													
HRU-612 LU FROM NI (ESF-DL)	SMJK	1111(F)1111(F)0100(4)1000(8)																													
HLU and HRU LD FROM NI OR CI		11100 11100 11100....																													
HLU and HRU LD FROM NI OR CI		100 100 100 ...																													
HLU and HRU LD FROM NI OR CI(ESF-DL)		1111(F)1111(F)0010(2)0100(4)																													
3	<p>The NREM, NLOC, CREM and CLOC loopbacks can also be initiated from the front panel of the HLU with the MODE and SEL pushbuttons. See Paragraph 7.20 for details.</p>																														

**TABLE 8. HLU-611 TEST PROCEDURES FOR A5LB OPTION**

Step	Action
1	Send into the HLU the inband ARMING and NIU (Network Interface Hit) LPBK code 11000 for at least five seconds, or at least four repetitions of the 16 bit ESF Data Link ARMING code 0001 0010 1111 1111.
2	Monitor the output of the HLU-611 for the return of the pattern. Return of pattern indicates that either the HRU has looped-up (if the SMART-JACK LOOPBACK option is ENABLED) or that an external NIU has looped up (if the SMART-JACK LOOPBACK option is DISABLED) and that the HLU and HRU units have been ARMED. Verify that the HLU display intermittently indicates "ARM" and also "SMJK" if the HRU is in loopback. Also verify, if possible, that the LOOPBACK LED of the HRU-612 is flashing, indicating that the HRU is armed or that it is on solid, indicating that it is both armed and in loopback.
3	<p>Once armed, the HLU can be looped back (NLOC in Figure 5) by sending IOR (Intelligent Office Repeater) LPBK activation code 1101 0011 1101 0011 for at least five seconds. The tester observes the following activation response:</p> <ul style="list-style-type: none"> <li>• two seconds of AIS (all ones), followed by:</li> <li>• five seconds of returning data pattern, followed by:</li> <li>• 231 logic errors (including the frame bits) occur in the returned pattern (20 errors if ILR-2 were sent), followed by normal looped data. Note that this error pattern will repeat every 20 seconds as long as the IOR loopback pattern is being sent. This same 20 second repeat scenario also applies to the different bit error signatures generated by the ILR, Time-Out Override and Query commands. Only 230 bit errors may be detected if the test set does not include frame errors in its bit error count.</li> </ul> <p>The HiGain-2 Line Hit is now in Logic Loopback (NLOC of Figure 5). The display on the HLU-611 periodically shows NLOC (network local loop) and ARM (the HLU is still armed) in addition to the margin displays. The Loopback Time-out option, which is user settable to NONE, 20, 60 or 120 minutes, determines the duration of this loopback unless it is overridden by the TIME-OUT OVERRIDE command or a loop down command is sent. If the Time-out Override code 1101 0101 1101 0110 is received, the activation response sequence described above is repeated and the automatic timed expiration of the loopback is inhibited. If this Time-out Override is sent, then the only way to loop the HLU down is to issue the IR (Intelligent Repeater) LPDN (loopdown) code 1001 0011 1001 0011 or to issue the NIU (Network Interface Hit) LPDN and Disarm code 11100. The automatic time-out timer is restored during subsequent loopback sessions. The loopback time-out timer is reset to 20, 60 or 120 minutes when any of the loopback commands, except Time Out Override, are sent.</p>

*Table continued on next page*

**TABLE 8. HLU-611 TEST PROCEDURES FOR A5LB OPTION (CONTINUED)**

Step	Action																																	
5	<p>Using the following codes, a network tester can activate loopbacks NLOC or NREM or SMJK (if enabled) shown in Figure 5. A customer tester can activate loopbacks CLOC or CREM.</p> <p style="text-align: center;"><b>Addressable 5 (A5LB) Repeater Loopback Commands</b></p> <table border="0" style="width: 100%;"> <tr> <td style="width: 35%;">ARMING or NIU LPBK (inband)</td> <td style="width: 30%;">Arming code</td> <td style="width: 35%;">11000 11000...</td> </tr> <tr> <td>ARMING or NIU LPBK (ESF Data Link)</td> <td>Arming code</td> <td>1111(F)*1111(F)0100(4)1000(8)</td> </tr> <tr> <td>IR LPDN or DISARM (inband)</td> <td>Disarming code</td> <td>11100 11100...</td> </tr> <tr> <td>DISARM (ESF Data Link)</td> <td>Disarming code</td> <td>1111(F)1111(F)0010(2)0100(4)</td> </tr> <tr> <td>IOR LPBK (NLOC and CREM 231 errors)</td> <td>HLU Loop up</td> <td>1101(D)0011(3)1101(D)0011(3)</td> </tr> <tr> <td>ILR-2 LPBK (NREM and NLOC 20 bit errors)</td> <td>HRU Loop up</td> <td>1100(C)0111(7)0100(4)0010(2)</td> </tr> <tr> <td>IR LPDN</td> <td>Loop down (HLU or HRU)</td> <td>1001(9)0011(3)1001(9)0011(3)</td> </tr> <tr> <td>IR QUERY LPBK</td> <td>Query loopback</td> <td>1101(D)0101(5)1101(D)0101(5)</td> </tr> <tr> <td>IR ALTERNATE QUERY LPBK</td> <td>Alternate Query loopback</td> <td>1101(D)0101(5)1110(E)1010(A)</td> </tr> <tr> <td>TIME-OUT OVERRIDE</td> <td>Loopback Time-out Override</td> <td>1101(D)0101(5)1101(D)0110(6)</td> </tr> <tr> <td>IOR POWER DOWN (HLU)</td> <td>Removes VHDSL line power</td> <td>0110(6)0111(7)0110(6)0111(7)</td> </tr> </table> <p>Note: The left most bit arrives first in all sequences. The detection algorithm functions reliably with a random 10E-3 bit error ratio (BER) on the facility. The IOR POWER DOWN code must remain present for the duration of the power down mode. When this code is removed, HiGain-2 returns to its normal unlooped and unarmed state. *This is the HEX number for the 4 bit group.</p>	ARMING or NIU LPBK (inband)	Arming code	11000 11000...	ARMING or NIU LPBK (ESF Data Link)	Arming code	1111(F)*1111(F)0100(4)1000(8)	IR LPDN or DISARM (inband)	Disarming code	11100 11100...	DISARM (ESF Data Link)	Disarming code	1111(F)1111(F)0010(2)0100(4)	IOR LPBK (NLOC and CREM 231 errors)	HLU Loop up	1101(D)0011(3)1101(D)0011(3)	ILR-2 LPBK (NREM and NLOC 20 bit errors)	HRU Loop up	1100(C)0111(7)0100(4)0010(2)	IR LPDN	Loop down (HLU or HRU)	1001(9)0011(3)1001(9)0011(3)	IR QUERY LPBK	Query loopback	1101(D)0101(5)1101(D)0101(5)	IR ALTERNATE QUERY LPBK	Alternate Query loopback	1101(D)0101(5)1110(E)1010(A)	TIME-OUT OVERRIDE	Loopback Time-out Override	1101(D)0101(5)1101(D)0110(6)	IOR POWER DOWN (HLU)	Removes VHDSL line power	0110(6)0111(7)0110(6)0111(7)
ARMING or NIU LPBK (inband)	Arming code	11000 11000...																																
ARMING or NIU LPBK (ESF Data Link)	Arming code	1111(F)*1111(F)0100(4)1000(8)																																
IR LPDN or DISARM (inband)	Disarming code	11100 11100...																																
DISARM (ESF Data Link)	Disarming code	1111(F)1111(F)0010(2)0100(4)																																
IOR LPBK (NLOC and CREM 231 errors)	HLU Loop up	1101(D)0011(3)1101(D)0011(3)																																
ILR-2 LPBK (NREM and NLOC 20 bit errors)	HRU Loop up	1100(C)0111(7)0100(4)0010(2)																																
IR LPDN	Loop down (HLU or HRU)	1001(9)0011(3)1001(9)0011(3)																																
IR QUERY LPBK	Query loopback	1101(D)0101(5)1101(D)0101(5)																																
IR ALTERNATE QUERY LPBK	Alternate Query loopback	1101(D)0101(5)1110(E)1010(A)																																
TIME-OUT OVERRIDE	Loopback Time-out Override	1101(D)0101(5)1101(D)0110(6)																																
IOR POWER DOWN (HLU)	Removes VHDSL line power	0110(6)0111(7)0110(6)0111(7)																																
6	<p>After testing is complete, send the universal loopdown [IR (Intelligent Repeater) LPDN] code if the system is to loopdown but remain ARMED. Send the disarm code 11100 if all the equipment is to be looped down, disarmed and returned to normal operation. Note that the ARMED mode has an automatic time-out of 120 minutes.</p>																																	
7	<p>The NREM, NLOC, CREM and CLOC loopbacks can also be initiated from the front panel of the HLU with the MODE and SEL pushbuttons. See Paragraph 7.20 for details.</p>																																	

**TABLE 9. HLU 4 CHARACTER FRONT PANEL MESSAGES**

Message	Full Name	Description
CREM	Customer Remote Loopback	Signal from customer is looped back to customer at HLU-611.
NLOC	Network Local Loopback	DSX signal is looped back to DSX at HLU.
CLOC	Customer Local Loopback	Signal from Customer is looped back to customer at HRU-612.
NREM	Network Remote Loopback	DSX signal is looped back to DSX at HRU.
SMJK	Remote Smartjack Loopback	Signal from DSX is looped back at HRU by the HRU smartjack module.
TLOS	Transmit Loss Of Signal	HRU is in a logic loopback state caused by a loss of its T1 input from the NI, if enabled via SAIS option.
FERR	Framing Bit Error Occurred	Framing bit error occurred at HLU T1 input.
LBPV	Local Bipolar Violation	A bipolar violation has been received at the T1 input to the HLU-611.
SIG	Signal	The HLU and HRU transceivers are trying to establish contact with each other.
ACQ	Acquire	The HLU and HRU multiplexers are trying to establish synchronization over each loop.
HES	VHDSL CRC Error	VHDSL CRC error.
ARM	HiGain-2 System ARMED	Armed to respond to Intelligent Repeater Loop Codes.
ACO	Alarm CutOff	A MNRALM has occurred, and been retired to an ACO condition, by depressing the SEL button on the HLU front panel.
SELF TEST		The HLU is in a self test mode. This occurs every power ON/OFF cycle.
ALRM	Alarm Condition Exists	A minor alarm MNRALM condition is in effect.
M=X	VHDSL Loop Margin	Indicates the power of the received VHDSL signal relative to noise. Any value of '06' or greater is adequate for reliable system operation.

*Table continued on next page*

**TABLE 9. HLU 4 CHARACTER FRONT PANEL MESSAGES (CONTINUED)**

Message	Full Name	Description
PWR FEED SHRT	Power Feed Short	Indicates a short across the VHDSL pair. This same message can occur with an HRU that is drawing the correct amount of power over good cable pairs, but can't communicate with the HRU.
PWR FEED OPEN	Power Feed Open	Indicates an open circuit in the TandR of either VHDSL pair.
PWR FEED OFF	Power Feed Off	VHDSL span power has been turned off from the HMSC program.
BAD RT?	No response from HRU	The HLU does not receive any response from the HRU. Thus the HRU's integrity is questionable.
VER	HLU Software Version #	This is displayed during the System Settings review mode. Depress the Mode button for three seconds.
LIST 0xL	HLU's List #	Displayed during System Settings review mode defined above.
FRM	Frame:SF, ESF, UNFR, NONE	Defines the type of frame pattern being received from the DSX-1. Displayed during System Settings mode defined above.
CODE	Line Code: AMI, B8ZS	This is the line code that the HLU is set to receive and transmit at its DSX-1 interface. Displayed during System Settings mode defined above.
LOSW	Loss of Sync Word	Indicates that the VHDSL loops has lost sync. Causes a minor alarm.
LLOS	Local Loss of Signal	Indicates that no signal is detected at the T1 input to the HLU. Causes a minor alarm.
RLOS	Remote Loss of Signal	Indicates that no signal is detected at the T1 input to the HRU. Causes a minor alarm.
DS1	DS1 BPV errors	Indicates that the number of BPVs at the HLU and HRU DS1 inputs that have exceeded the 24 hour ES threshold. Causes a minor alarm.
DS0	DS0 Blocked Channels	Indicates status of DS0 blocked channels. NONE indicates no channels are blocked. BLK indicates some channels are blocked.
MAL	Margin Alarm	The margin on the VHDSL loop has dropped below the threshold (0 to 15 dB) set by the user.

\* These messages are only available when using the HMSC PC based main system.



**TABLE 10. HLU-611 STATUS MENU DEFINITIONS**

<i>Message</i>	<i>Full Name</i>	<i>Description</i>
<b>ALARMS</b>		
NONE	No Alarms	
LLOS	Local Loss of Signal	No signal from local T1 interface.
RLOS	Remote Loss of Signal	No signal from remote T1 interface.
LOSW	Loss of Sync Word	The VHDSL's loop has lost sync.
HES	VHDSL Errored Second	The VHDSL's CRC errors have exceeded the user-selected ES threshold.
DS1	Digital Service 1	DS1 input BPVs have exceeded the user-selected ES threshold.
LAIS	Local Alarm Indicating Signal	Indicates an AIS (all 1's) pattern is being transmitted from the local T1 output port.
RAIS	Remote Alarm Indicating Signal	Indicates an AIS (all 1's) pattern is being transmitted from the remote T1 output port.
MAL	Margin Alarm VHDSL	The margin on the VHDSL Loop has dropped below the user Margin Alarm Threshold (1 to 15). Setting the threshold to 0 (zero) inhibits the alarm.
<b>LOOPBACKS</b>		
SMJK	Smartjack Loopback	Loopback at HRU towards network initiated by 2 in 5 in-band loopback code or out-of-band ESF data link code. See Figure 5.
NREM	Network Remote Loopback	Loopback at HRU (remote) towards network initiated by addressable line repeater code, HRU front panel push-button, HLU front panel manual loopback push-button, or maintenance terminal. See Figure 5.
NLOC	Network Local Loopback	Loopback at HLU (local) towards network initiated by addressable office repeater code, HLU front panel manual loopback push-button, or maintenance terminal. See Figure 5.
CLOC	Customer Local Loopback	Loopback at HRU (local) towards CI initiated by addressable line repeater code, HLU front panel manual loopback push-button, or maintenance terminal. See Figure 5.
CREM	Customer Remote Loopback	Loopback at HLU (remote) towards customer initiated by addressable office repeater code, HLU front panel manual loopback push-button, or maintenance terminal. See Figure 5.
ARM	Armed	HiGain has detected the addressable repeater loopback (2 in 5) arming code.
TLOS	Transmit Loss of Signal Loopback	HRU is in a logic loopback state caused by a loss of its T1 input from the NI, if enabled via SAIS option.

```
HI-GAIN HLU-611  MAINTENANCE TERMINAL MAIN MENU  (ver U1.4L-0001)
                  CIRCUIT ID#: PairGain Technologies

                  A. VIEW SPAN STATUS
                  B. SET CLOCK
                  C. SYSTEM SETTINGS
                  D. LOOPBACK MODE: NONE
                  E. VIEW PERFORMANCE DATA
                  F. VIEW PERFORMANCE HISTORY
                  G. VIEW ALARM HISTORY
                  H. ENTER CIRCUIT ID #
```

Figure 6. HLU-611 Main Menu.

```
                  SPAN STATUS
(HLU/ver1.4-0001:HRU/ver1.0-0001)

TIME: 01:14:05
DATE: 07/19/95                CIRCUIT ID#: PairGain Technologies

ALARMS: LAIS RAIS LLOS RLOS
LOOPBACK: OFF

                HLU                      HRU
                HDSL                      HDSL
                cur/min/max              cur/min/max
MARGIN:         20/18/21                  20/18/20 dB
PULSE ATTN:    00                        00 dB
PPM OFFSET:    00                        -08 ppm
24 HOUR ES:    00001                     00002 seconds
24 HOUR UAS:   00016                     00000 seconds

                  DS1 STATUS

                HLU                      HRU
24 HOUR BPU Seconds: 00000                00002
24 HOUR UAS Count:  04446                 04432
Frame type:         No Activity            No Activity
Code type:          AMI                    AMI

(E)xit (C)lear (U)pdate█
```

Figure 7. HLU Status Display.

```
                                SET CLOCK

TIME: 01:18:09
DATE: 07/19/95
CIRCUIT ID#: PairGain Technologies

Format: HH:MM
        MM/DD/YY

NEW TIME:

NEW DATE:

(U)PDATE REMOTE?█
```

Figure 8. Set Clock Menu.

```
                                SYSTEM SETTINGS

TIME: 01:21:18
DATE: 07/19/95
                                CIRCUIT ID#: PairGain Technologies

E(Q)UALIZATION:      EXT
SMART-JACK (L)B:     ENABLE
(S)PECIAL LPBK:      GNLB
(P)OWER:              ENABLE
(Z)BTSI:              OFF
ES ALARM TH(R)ES:    NONE
LOOPBACK (T)IMEOUT:  60
(A)LARM:              DISABLE
(D)S1 LINE CODE:     AMI
(F)RAMING:            AUTO
AIS ON (H)DSL ALRM:  DISABLE
AIS ON S(M)JK/NREM:  ENABLE
MAR(G)IN ALM THRES:  4
DSD (B)LOCKING: xx - Blocked Channels
01 02 03 04 05 06 07 08 09 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24

                                (E)xit
Enter the letter in parenthesis (X) to change any setting█
```

Figure 9. System Settings Menu.




FIGURE 10. Performance Data.




Figure 11. Performance Data History.

ALARM HISTORY				
TIME: 02:19:32				
DATE: 07/19/95				
CIRCUIT ID#: PairGain Technologies				
Type	First	Last	Current	Count
LOS, DS1-HLU	07/19/95-00:00	07/19/95-00:00	ALARM	001
LOS, DS1-HRU	07/19/95-00:00	07/19/95-00:00	ALARM	001
LOSW, HDL	07/19/95-00:00	07/19/95-00:00	OK	001
ES, HDL			OK	000
MARGIN LP			OK	000
PWR-OPEN			OK	000
PWR-SHRT	07/19/95-00:00	07/19/95-00:00	OK	001
LAST CLEARED: NONE				
(E)xit (C)lear (U)pdate				

Figure 12. HLU Alarm History.